TI01221D/06/EN/06.18

71415035 2018-11-01

Technical Information Proline Promass F 300

Coriolis flowmeter



The flowmeter with premium accuracy, robustness and a compact, easily accessible transmitter

Application

- Measuring principle operates independently of physical fluid properties such as viscosity or density
- Highest measurement performance for liquids and gases under varying, demanding process conditions

Device properties

- Mass flow: measured error ±0.05 % (PremiumCal)
- Medium temperature: -196 to +350 °C (-320 to +662 °F)
- Nominal diameter: DN 8 to 250 ($\frac{3}{8}$ to 10")
- Compact dual-compartment housing with up to 3 I/Os
- Backlit display with touch control and WLAN access
- Remote display available

Your benefits

- Highest process safety immune to fluctuating and harsh environments
- Fewer process measuring points multivariable measurement (flow, density, temperature)
- Space-saving installation no inlet/outlet run needs
- Full access to process and diagnostic information numerous, freely combinable I/Os and fieldbuses
- Reduced complexity and variety freely configurable I/O functionality
- Integrated verification Heartbeat Technology



Table of contents

About this document	4 4
Function and system design Measuring principle Measuring system Equipment architecture Safety	.5 .7 8
Input	11 11 12 12
OutputOutput and input variantsOutput signalSignal on alarmSignal on alarmSignal on data	14 14 15 19 21 22 22 22
Power supply Terminal assignment Device plugs available Pin assignment, device plug Supply voltage Power consumption . Current consumption . Power supply failure . Electrical connection Potential equalization . terminals . Cable entries . Cable specification .	27 28 29 30 31 31 31 32 41 41 41
Performance characteristics Reference operating conditions Maximum measured error Repeatability Response time Influence of ambient temperature Influence of medium temperature Influence of medium pressure Design fundamentals Installation Mounting location Orientation Inlet and outlet runs Special mounting instructions	44 44 44 46 46 46 47 47 48 49 50 50 50
Environment Ambient temperature range Storage temperature	52 52 52

Climate class	52 52
Vibration resistance	52 52
Shock resistance	52
Interior cleaning	52
Electromagnetic compatibility (EMC)	52
Process	53
Medium temperature range	53 54
Pressure-temperature curves	54
Sensor housing	59
Rupture disk	60 60
Flow limit	60 60
System pressure	60
Thermal insulation	61
Heating	61 62
Vibrations	62
Custody transfer measurement	63
Mechanical construction	64
Dimensions in SI units	64
Dimensions in US units	85 95
Materials	95 96
Process connections	99
Surface roughness	99
Operability	99
Operating concept	99
Languages	99 100
	101
Service interface	106
	107
	108 109
	107
11	111 111
	111
	111
Sanitary compatibility	112
F	112 112
	112
	113
Certification PROFIBUS	113
	113
	113 113
	エエン
	113
Measuring instrument approval	113
Measuring instrument approval	

Ordering information	115
Application packagesDiagnostics functionsHeartbeat TechnologyConcentrationSpecial densityPetroleumOPC-UA server	115 115 116 116 116 116 116
Accessories	116 117 118 119 119
Supplementary documentation	120 120 120
Registered trademarks	121

About this document

Symbols used

Electrical symbols

Symbol	Meaning
	Direct current
\sim	Alternating current
8	Direct current and alternating current
4	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective Earth (PE) A terminal which must be connected to ground prior to establishing any other connections.
	The ground terminals are situated inside and outside the device:Inner ground terminal: Connects the protectiv earth to the mains supply.Outer ground terminal: Connects the device to the plant grounding system.

Communication symbols

Symbol	Meaning
(î•	Wireless Local Area Network (WLAN) Communication via a wireless, local network.
	LED Light emitting diode is off.
-\$	LED Light emitting diode is on.
	LED Light emitting diode is flashing.

Symbols for certain types of information

Symbol	Meaning
	Permitted Procedures, processes or actions that are permitted.
	Preferred Procedures, processes or actions that are preferred.
×	Forbidden Procedures, processes or actions that are forbidden.
i	Tip Indicates additional information.
	Reference to documentation.
	Reference to page.
	Reference to graphic.
	Visual inspection.

Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
1., 2., 3.,	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections
EX	Hazardous area
X	Safe area (non-hazardous area)
≈➡	Flow direction

Function and system design

Measuring principle


The measuring principle is based on the controlled generation of Coriolis forces. These forces are always present in a system when both translational and rotational movements are superimposed.

- $F_c = 2 \cdot \Delta m (v \cdot \omega)$
- F_c = Coriolis force
- $\Delta m = moving mass$
 - ω = rotational velocity
 - v = radial velocity in rotating or oscillating system

The amplitude of the Coriolis force depends on the moving mass Δm , its velocity v in the system and thus on the mass flow. Instead of a constant rotational velocity ω , the sensor uses oscillation.

In the sensor, two parallel measuring tubes containing flowing fluid oscillate in antiphase, acting like a tuning fork. The Coriolis forces produced at the measuring tubes cause a phase shift in the tube oscillations (see illustration):

- At zero flow (when the fluid is at a standstill) the two tubes oscillate in phase (1).
- Mass flow causes deceleration of the oscillation at the inlet of the tubes (2) and acceleration at the outlet (3).



The phase difference (A-B) increases with increasing mass flow. Electrodynamic sensors register the tube oscillations at the inlet and outlet. System balance is ensured by the antiphase oscillation of the two measuring tubes. The measuring principle operates independently of temperature, pressure, viscosity, conductivity and flow profile.

Density measurement

The measuring tube is continuously excited at its resonance frequency. A change in the mass and thus the density of the oscillating system (comprising measuring tube and fluid) results in a corresponding, automatic adjustment in the oscillation frequency. Resonance frequency is thus a function of medium density. The microprocessor utilizes this relationship to obtain a density signal.

Volume measurement

Together with the measured mass flow, this is used to calculate the volume flow.

Temperature measurement


The temperature of the measuring tube is determined in order to calculate the compensation factor due to temperature effects. This signal corresponds to the process temperature and is also available as an output signal.

Measuring system


The device consists of a transmitter and a sensor.

The device is available as a compact version: The transmitter and sensor form a mechanical unit.


Transmitter



Sensor



Equipment architecture



I Possibilities for integrating measuring devices into a system

- 1 Control system (e.g. PLC)
- 2 Connecting cable (0/4 to 20 mA HART etc.)
- 3 Fieldbus
- 4 Segment coupler
- 5 Non-hazardous area
- 6 Hazardous area: Zone 2; Class I, Division 2
- 7 Hazardous area: Zone 1; Class I, Division 1

Safety

IT security

Our warranty is valid only if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the device and associated data transfer, must be implemented by the operators themselves in line with their security standards.

Device-specific IT security

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater in-operation safety if used correctly. An overview of the most important functions is provided in the following section.

Function/interface	Factory setting	Recommendation
Write protection via hardware write protection switch $\Rightarrow \textcircled{B} 9$	Not enabled.	On an individual basis following risk assessment.
Access code (also applies for Web server login or FieldCare connection) $\rightarrow \square 9$	Not enabled (0000).	Assign a customized access code during commissioning.
WLAN (order option in display module)	Enabled.	On an individual basis following risk assessment.
WLAN security mode	Enabled (WPA2- PSK)	Do not change.
WLAN passphrase (password) → 🗎 9	Serial number	Assign a customized access code during commissioning.
WLAN mode	Access Point	On an individual basis following risk assessment.
Web server→ 🗎 9	Enabled.	On an individual basis following risk assessment.
CDI-RJ45 service interface → 🗎 10	-	On an individual basis following risk assessment.

Protecting access via hardware write protection

Write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be disabled via a write protection switch (DIP switch on the motherboard). When hardware write protection is enabled, only read access to the parameters is possible.

Hardware write protection is disabled when the device is delivered.

Protecting access via a password

Different passwords are available to protect write access to the device parameters or access to the device via the WLAN interface.

User-specific access code

Protect write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare). Access authorization is clearly regulated through the use of a user-specific access code.

WLAN passphrase

The network key protects a connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface which can be ordered as an option.

Infrastructure mode
 When the device is operated in infrastructure mode, the WLAN passphrase corresponds to the
 WLAN passphrase configured on the operator side.

User-specific access code

Write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be protected by the modifiable, user-specific access code.

WLAN passphrase: Operation as WLAN access point

A connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface, which can be ordered as an optional extra, is protected by the network key. The WLAN authentication of the network key complies with the IEEE 802.11 standard.

When the device is delivered, the network key is pre-defined depending on the device. It can be changed via the **WLAN settings** submenu in the **WLAN passphrase** parameter.

Infrastructure mode

A connection between the device and WLAN access point is protected by means of an SSID and passphrase on the system side. Please contact the relevant system administrator for access.

General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning.
- Follow the general rules for generating a secure password when defining and managing the access code or network key.
- The user is responsible for the management and careful handling of the access code and network key.

Access via Web server

The device can be operated and configured via a Web browser with the integrated Web server. The connection is via the service interface (CDI-RJ45) or the WLAN interface. For device versions with the EtherNet/IP and PROFINET communication protocols, the connection can also be established via the terminal connection for signal transmission with EtherNet/IP or PROFINET (RJ45 connector).

The Web server is enabled when the device is delivered. The Web server can be disabled if necessary (e.g. after commissioning) via the **Web server functionality** parameter.

The device and status information can be hidden on the login page. This prevents unauthorized access to the information.



For detailed information on device parameters, see: The "Description of Device Parameters" document $\rightarrow \square 120$

Access via OPC-UA



The "OPC UA Server" application package is available in the device version with the HART communication protocol $\rightarrow \cong 116$.

The device can communicate with OPC UA clients using the "OPC UA Server" application package.

The OPC UA server integrated in the device can be accessed via the WLAN access point using the WLAN interface - which can be ordered as an optional extra - or the service interface (CDI- RJ45) via Ethernet network. Access rights and authorization as per separate configuration.

The following Security Modes are supported as per the OPC UA Specification (IEC 62541):

- None
- Basic128Rsa15 signed
- Basic128Rsa15 signed and encrypted

Access via service interface (CDI-RJ45)

The device can be connected to a network via the service interface (CDI-RI45). Device-specific functions guarantee the secure operation of the device in a network.

The use of relevant industrial standards and guidelines that have been defined by national and international safety committees, such as IEC/ISA62443 or the IEEE, is recommended. This includes organizational security measures such as the assignment of access authorization as well as technical measures such as network segmentation.

The device can be integrated in a ring topology. The device is integrated via the terminal connection for signal transmission (output 1) and the connection to the service interface (CDI-RJ45) → 🖺 104.

Input

Measured variable	Direct measured variables
	Mass flowDensityTemperature
	Calculated measured variables
	Volume flowCorrected volume flowReference density
Measuring range	Measuring range for liquids

Measuring range

Measuring range for liquids

DN		Measuring range full scale values $\dot{m}_{min(F)}$ to $\dot{m}_{max(F)}$	
[mm]	[in]	[kg/h]	[lb/min]
8	3⁄8	0 to 2 000	0 to 73.50
15	1⁄2	0 to 6 500	0 to 238.9
25	1	0 to 18000	0 to 661.5
40	11/2	0 to 45 000	0 to 1654
50	2	0 to 70 000	0 to 2 573
80	3	0 to 180 000	0 to 6 6 1 5
100	4	0 to 350 000	0 to 12860
150	6	0 to 800 000	0 to 29400
250	10	0 to 2 200 000	0 to 80850

Measuring range for gases

The full scale value depends on the density and the sound velocity of the gas used and can be calculated with the formula below:

 $\dot{m}_{max(G)} = minimum \ (\dot{m}_{max(F)} \cdot \rho_G : x \text{ ; } \rho_G \cdot c_G \cdot \pi/2 \cdot (d_i)^2 \cdot 3600)$

m _{max(G)}	Maximum full scale value for gas [kg/h]	
m _{max(F)}	Maximum full scale value for liquid [kg/h]	
$\dot{m}_{\max(G)} < \dot{m}_{\max(F)}$	$\dot{m}_{\max(G)}$ can never be greater than $\dot{m}_{\max(F)}$	
ρ _G	Gas density in [kg/m³] at operating conditions	
x	Constant dependent on nominal diameter	
CG	Sound velocity (gas) [m/s]	
di	Measuring tube internal diameter [m]	

DN		x
[mm]	[in]	[kg/m³]
8	3⁄8	60
15	1/2	80
25	1	90
40	11/2	90
50	2	90
80	3	110

	D	N	x			
	[mm]	[in]	[kg/m³]			
	100	4	130			
	150	6	200			
	250	10	200			
	To calculate the mean Calculation example for • Sensor: Promass F, DN	gas	pplicator sizing tool → 🗎 119			
	 Gas: Air with a density Measuring range (liqui x = 90 kg/m³ (for Prom 	of 60.3 kg/m³ (at 20 °C a d): 70 000 kg/h	nd 50 bar)			
	$\begin{array}{l} \text{Maximum possible full sc} \\ \dot{m}_{\max(G)} = \dot{m}_{\max(F)} \cdot \rho_G : x \end{array}$		m ³ : 90 kg/m ³ = 46 900 kg/h			
	Recommended measuring	ng range				
	"Flow limit" section \rightarrow	"Flow limit" section $\rightarrow \triangleq 60$				
Operable flow range	Over 1000 : 1.					
operable now range	Over 1000 : 1. Flow rates above the preset full scale value do not override the electronics unit, with the result the totalizer values are registered correctly.					
Input signal	Input and output version	15				
	$\rightarrow \cong 14$					
	External measured values					
	 To increase the accuracy of certain measured variables or to calculate the corrected volume flow for gases, the automation system can continuously write different measured values to the measuring device: Operating pressure to increase accuracy (Endress+Hauser recommends the use of a pressure measuring device for absolute pressure, e.g. Cerabar M or Cerabar S) 					
	 Medium temperature to increase accuracy (e.g. iTEMP) Reference density for calculating the corrected volume flow for gases 					
	Various pressure transmitters and temperature measuring devices can be ordered from Endress +Hauser: see "Accessories" section → 🗎 119					
	It is recommended to read in external measured values to calculate the corrected volume flow.					
	HART protocol					
	The measured values are written from the automation system to the measuring device via the HART protocol. The pressure transmitter must support the following protocol-specific functions: • HART protocol • Burst mode					
	Current input					
	The measured values are written from the automation system to the measuring device via the current input $\rightarrow \equiv 13$.					
	Digital communication					
	The measured values can FOUNDATION Fieldbus PROFIBUS DP PROFIBUS PA Modbus RS485 FthorNat/(P		mation system to the measuring via:			

PROFINET

Current input 0/4 to 20 mA

Current input	0/4 to 20 mA (active/passive)
Current span	 4 to 20 mA (active) 0/4 to 20 mA (passive)
Resolution	1 μΑ
Voltage drop	Typically: 0.6 to 2 V for 3.6 to 22 mA (passive)
Maximum input voltage	≤ 30 V (passive)
Open-circuit voltage	< 28.8 V (active)
Possible input variables	PressureTemperatureDensity

Status input

Maximum input values	 DC -3 to 30 V If status input is active (ON): R_i >3 kΩ
Response time	Adjustable: 5 to 200 ms
Input signal level	 Low signal: DC -3 to +5 V High signal: DC 12 to 30 V
Assignable functions	 Off Reset the individual totalizers separately Reset all totalizers Flow override

Output

Output and input variants

Depending on the option selected for output/input 1, different options are available for the other outputs and inputs. Only one option can be selected for each output/input 1 to 3. The table must be read vertically (\downarrow).

Example: If the option BA "4–20 mA HART" was selected for output/input 1, one of the options A, B, D, E, F, H, I or J is available for output 2 and one of the options A, B, D, E, F, H, I or J is available for output 3.

Order code for "Output; input 1" (020) \rightarrow			Possible options							
Current output 4 to 20 mA HART	BA									
Current output 4 to 20 mA HART Ex i	\downarrow	CA								
FOUNDATION Fieldbus		\downarrow	SA							
FOUNDATION Fieldbus Ex i			\downarrow	TA						
PROFIBUS DP				\downarrow	LA					
PROFIBUS PA					\downarrow	GA				
PROFIBUS PA Ex i						\downarrow	HA			
Modbus RS485							\downarrow	MA		
EtherNet/IP 2-port switch integrated								\downarrow	NA	
PROFINET 2-port switch integrated									\downarrow	RA
Order code for "Output; input 2" (021) \rightarrow	\checkmark	\downarrow	\downarrow	\downarrow	\downarrow	\downarrow	\downarrow	\downarrow	\downarrow	\downarrow
Not assigned	A	A	A	Α	A	Α	A	Α	A	A
Current output 0/4 to 20 mA	В		В		В	В		В	В	В
Current output 0/4 to 20 mA (Ex i)		С		С			C			
User configurable input/output ¹⁾	D		D		D	D		D	D	D
Pulse/frequency/switch output	E		Е		E	E		E	E	E
Double pulse output ²⁾	F							F		
Pulse/frequency/switch output (Ex i)		G		G			G			
Relay output	Н		н		н	н		н	н	н
Current input 0/4 to 20 mA	I		I		I	I		I	I	I
Status input	J		J		J	J		J	J	J
Order code for "Output; input 3" (022) \rightarrow	\downarrow	\downarrow	\downarrow	\downarrow	\downarrow	\downarrow	\downarrow	\downarrow	\downarrow	\downarrow
Not assigned	A	A	Α	Α	A	Α	A	A	A	A
Current output 0/4 to 20 mA	В				В			В	В	В
Current output 0/4 to 20 mA (Ex i)		С								
User configurable input/output	D				D			D	D	D
Pulse/frequency/switch output	E				E			E	E	E
Double pulse output (slave) ²⁾	F							F		
Pulse/frequency/switch output (Ex i)		G								
Relay output	Н				н			н	н	н
Current input 0/4 to 20 mA	I				I			I	I	Ι
Status input	J				J			J	J	J

1) A specific input or output can be assigned to a user configurable input/output $\rightarrow \square$ 18.

2) If double pulse output (F) is selected for output/input 2 (021), only the double pulse output (F) option is available for selection for output/input 3 (022).

Output signal

HART current output

Current output	4 to 20 mA HART	
Current span	Can be set to: 4 to 20 mA (active/passive)	
	Ex-i, passive	
Open-circuit voltage	DC 28.8 V (active)	
Maximum input voltage	DC 30 V (passive)	
Load	250 to 700 Ω	
Resolution	0.38 μΑ	
Damping	Configurable: 0.07 to 999 s	
Assignable measured variables	 Mass flow Volume flow Corrected volume flow Density Reference density Temperature Electronic temperature Oscillation frequency 0 Oscillation damping 0 Signal asymmetry Exciter current 0 Image of options increases if the measuring device has one or more application packages. 	

PROFIBUS PA

PROFIBUS PA	In accordance with EN 50170 Volume 2, IEC 61158-2 (MBP), galvanically isolated
Data transmission	31.25 kbit/s
Current consumption	10 mA
Permitted supply voltage	9 to 32 V
Bus connection	With integrated reverse polarity protection

PROFIBUS DP

Signal encoding	NRZ code
Data transfer	9.6 kBaud12 MBaud

EtherNet/IP

Standards	In accordance with IEEE 802.3
-----------	-------------------------------

PROFINET

Standards	In accordance with IEEE 802.3
-----------	-------------------------------

FOUNDATION Fieldbus

FOUNDATION Fieldbus	H1, IEC 61158-2, galvanically isolated
Data transfer	31.25 kbit/s

Current consumption	10 mA
Permitted supply voltage	9 to 32 V
Bus connection	With integrated reverse polarity protection

Modbus RS485

Physical interface	RS485 in accordance with EIA/TIA-485 standard
Terminating resistor	Integrated, can be activated via DIP switches

Current output 0/4 to 20 mA

Current output	0/4 to 20 mA
Maximum output values	22.5 mA
Current span	Can be set to:
	 4 to 20 mA (active) 0/4 to 20 mA (passive)
	Ex-i, passive
Open-circuit voltage	DC 28.8 V (active)
Maximum input voltage	DC 30 V (passive)
Load	0 to 700 Ω
Resolution	0.38 μΑ
Damping	Adjustable: 0.07 to 999 s
Assignable measured variables	 Mass flow Volume flow Corrected volume flow Density Reference density Temperature Electronic temperature Oscillation frequency 0 Oscillation damping 0 Signal asymmetry Exciter current 0 Image of options increases if the measuring device has one or more application packages.

Pulse/frequency/switch output

Function	Can be set to pulse, frequency or switch output
Version	Open collector Can be set to: • Active • Passive In Ex-i, passive
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Voltage drop	For 22.5 mA: ≤ DC 2 V
Pulse output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)

Open-circuit voltage	DC 28.8 V (active)
Pulse width	Adjustable: 0.05 to 2 000 ms
Maximum pulse rate	10 000 Impulse/s
Pulse value	Adjustable
Assignable measured variables	Mass flowVolume flowCorrected volume flow
Frequency output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Output frequency	Adjustable: end value frequency 2 to 10000 Hz (f $_{max}$ = 12500 Hz)
Damping	Adjustable: 0 to 999 s
Pulse/pause ratio	1:1
Assignable measured variables	 Mass flow Volume flow Corrected volume flow Density Reference density Temperature Electronic temperature Oscillation frequency 0 Oscillation damping 0 Signal asymmetry Exciter current 0 Image of options increases if the measuring device has one or more application packages.
Switch output	
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Switching behavior	Binary, conductive or non-conductive
Switching delay	Adjustable: 0 to 100 s
Number of switching cycles	Unlimited
Assignable functions	 Off On Diagnostic behavior Limit value Mass flow Volume flow Corrected volume flow Density Reference density Temperature Totalizer 1-3 Flow direction monitoring Status Partially filled pipe detection Low flow The range of options increases if the measuring device has one or more application packages.

Double pulse output

Function	Double pulse
Version	Open collector
	Can be set to: • Active • Passive
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Voltage drop	For 22.5 mA: ≤ DC 2 V
Output frequency	Adjustable: 0 to 1 000 Hz
Damping	Adjustable: 0 to 999 s
Pulse/pause ratio	1:1
Assignable measured variables	 Mass flow Volume flow Corrected volume flow Density Reference density Temperature The range of options increases if the measuring device has one or more application packages.

Relay output

Function	Switch output
Version	Relay output, galvanically isolated
Switching behavior	Can be set to: • NO (normally open), factory setting • NC (normally closed)
Maximum switching capacity (passive)	 DC 30 V, 0.1 A AC 30 V, 0.5 A
Assignable functions	 Off On Diagnostic behavior Limit value Mass flow Volume flow Corrected volume flow Density Reference density Temperature Totalizer 1-3 Flow direction monitoring Status Partially filled pipe detection Low flow In range of options increases if the measuring device has one or more application packages.

User configurable input/output

One specific input or output is assigned to a user-configurable input/output (configurable I/O) during device commissioning.

The following inputs and outputs are available for assignment:

- Choice of current output: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Pulse/frequency/switch output
- Choice of current input: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Status input

The technical values correspond to those of the inputs and outputs described in this section.

Signal on alarm

Depending on the interface, failure information is displayed as follows:

HART current output

Device diagnostics	Device condition can be read out via HART Command 48

PROFIBUS PA

Status and alarm messages	Diagnostics in accordance with PROFIBUS PA Profile 3.02
Failure current FDE (Fault Disconnection Electronic)	0 mA

PROFIBUS DP

Status and alarm	Diagnostics in accordance with PROFIBUS PA Profile 3.02
messages	

EtherNet/IP

Device diagnostics Device condition can be read out in Input Assembly
--

PROFINET

Device diagnostics According to "Application Layer protocol for decentralized periphery", Version 2.
--

FOUNDATION Fieldbus

Status and alarm messages	Diagnostics in accordance with FF-891
Failure current FDE (Fault Disconnection Electronic)	0 mA

Modbus RS485

Failure mode	Choose from:
	 NaN value instead of current value
	 Last valid value

Current output 0/4 to 20 mA

4 to 20 mA

Failure mode	 Choose from: 4 to 20 mA in accordance with NAMUR recommendation NE 43 4 to 20 mA in accordance with US Min. value: 3.59 mA Max. value: 22.5 mA Freely definable value between: 3.59 to 22.5 mA Actual value
	 Last valid value

0 to 20 mA

Failure mode	Choose from:
	Maximum alarm: 22 mAFreely definable value between: 0 to 20.5 mA

Pulse/frequency/switch output

Pulse output	Pulse output		
Failure mode	Choose from: • Actual value • No pulses		
Frequency output			
Failure mode	Choose from: • Actual value • 0 Hz • Defined value (f _{max} 2 to 12 500 Hz)		
Switch output			
Failure mode	Choose from: • Current status • Open • Closed		

Relay output

Failure mode	Choose from: • Current status • Open • Closed

Local display

Plain text display	With information on cause and remedial measures
Backlight	Red backlighting indicates a device error.

Status signal as per NAMUR recommendation NE 107

Interface/protocol

- Via digital communication:
 - HART protocol
 - FOUNDATION Fieldbus
 - PROFIBUS PA
 - PROFIBUS DP
 - Modbus RS485 - EtherNet/IP
 - PROFINET
- Via service interface
 - CDI-RJ45 service interface
 - WLAN interface

Plain text display

With information on cause and remedial measures

Additional information on remote operation $\rightarrow \square 101$

Web server

Plain text display	With information on cause and remedial measures
--------------------	---

Light emitting diodes (LED)

Status information	Status indicated by various light emitting diodes	
	The following information is displayed depending on the device version: Supply voltage active Data transmission active Device alarm/error has occurred EtherNet/IP network available EtherNet/IP connection established PROFINET network available PROFINET connection established PROFINET connection established PROFINET blinking feature 	

Ex connection data

Safety-related values

Order code for "Output; input 1"	Output type	Safety-related values "Output; input 1"		
		26 (+)	27 (-)	
Option BA	Current output 4 to 20 mA HART	$\begin{array}{l} U_N = 30 \ V_{DC} \\ U_M = 250 \ V_{AC} \end{array}$		
Option GA	PROFIBUS PA	$U_{\rm N} = 30 V_{\rm DC}$ $U_{\rm M} = 250 V_{\rm AC}$		
Option LA	PROFIBUS DP	$U_{\rm N} = 30 V_{\rm DC}$ $U_{\rm M} = 250 V_{\rm AC}$		
Option MA	Modbus RS485	$U_{\rm N} = 30 V_{\rm DC}$ $U_{\rm M} = 250 V_{\rm AC}$		
Option SA	FOUNDATION Fieldbus	$U_{\rm N} = 30 V_{\rm DC}$ $U_{\rm M} = 250 V_{\rm AC}$		
Option NA	EtherNet/IP	$U_{\rm N} = 30 V_{\rm DC}$ $U_{\rm M} = 250 V_{\rm AC}$		
Option RA	PROFINET	$U_{\rm N} = 30 \ V_{\rm DC}$ $U_{\rm M} = 250 \ V_{\rm AC}$		

Order code for	Output type Safety-related values				
"Output; input 2"; "Output; input 3"		Output; input 2 Output; inpu		input 3	
x ' x		24 (+)	25 (-)	22 (+)	23 (-)
Option B	Current output 4 to 20 mA	$U_{N} = 30 V_{DC}$ $U_{M} = 250 V_{AC}$			
Option D	User configurable input/ output	$U_{N} = 30 V_{DC}$ $U_{M} = 250 V_{AC}$			
Option E	Pulse/frequency/switch output	$U_{\rm N} = 30 V_{\rm DC}$ $U_{\rm M} = 250 V_{\rm AC}$	2		
Option F	Double pulse output	$\begin{array}{l} U_N = 30 \ V_{DC} \\ U_M = 250 \ V_{AC} \end{array}$			
Option H	Relay output	$ \begin{array}{l} U_{N} = 30 \; V_{DC} \\ I_{N} = 100 \; mA_{DC} / 500 \; mA_{AC} \\ U_{M} = 250 \; V_{AC} \end{array} $			
Option I	Current input 4 to 20 mA	$U_{\rm N} = 30 V_{\rm DC}$ $U_{\rm M} = 250 V_{\rm AC}$			
Option J	Status input	$U_{\rm N} = 30 V_{\rm DC}$ $U_{\rm M} = 250 V_{\rm AC}$	2		

Intrinsically safe values

Order code for "Output; input 1"	Output type	Intrinsically safe values "Output; input 1"	
		26 (+)	27 (-)
Option CA	Current output 4 to 20 mA HART Ex i	$\begin{array}{l} U_{i} = 30 \ V \\ l_{i} = 100 \ mA \\ P_{i} = 1.25 \ W \\ L_{i} = 0 \\ C_{i} = 0 \end{array}$	
Option HA	PROFIBUS PA Ex i		$ \begin{array}{l} \textbf{Ex ic}^{2)} \\ U_{i} = 32 \ V \\ l_{i} = 570 \ \text{mA} \\ P_{i} = 8.5 \ W \\ L_{i} = 10 \ \mu\text{H} \\ C_{i} = 5 \ \text{nF} \end{array} $
Option TA	FOUNDATION Fieldbus Ex i		Ex ic ²⁾ $U_i = 32 V$ $l_i = 570 mA$ $P_i = 8.5 W$ $L_i = 10 \mu H$ $C_i = 5 nF$

1) Only available for the Zone 1; Class I, Division 1 version

2) Only available for the Zone 2; Class I, Division 2 version transmitter

Order code for	Output type	Intrinsically safe values or NIFW values			
"Output; input 2"; "Output; input 3"		Output;	input 2	Output;	input 3
• • •		24 (+)	25 (-)	22 (+)	23 (-)
Option C	Current output 4 to 20 mA Ex i	$\begin{array}{l} U_i = 30 \ V \\ l_i = 100 \ mA \\ P_i = 1.25 \ W \\ L_i = 0 \\ C_i = 0 \end{array}$			
Option G	Pulse/frequency/switch output Ex i	$\begin{array}{l} U_i = 30 \ V \\ l_i = 100 \ mA \\ P_i = 1.25 \ W \\ L_i = 0 \\ C_i = 0 \end{array}$			

Low flow cut off

The switch points for low flow cut off are user-selectable.

Galvanic isolation

The outputs are galvanically isolated from one another and from earth (PE).

Protocol-specific data

HART

Manufacturer ID	0x11
Device type ID	0x3B
HART protocol revision	7
Device description files (DTM, DD)	Information and files under: www.endress.com
HART load	Min. 250 Ω
System integration	 Information on system integration: Operating Instructions → [□] 120. Measured variables via HART protocol Burst Mode functionality

PROFIBUS PA

Manufacturer ID	0x11				
Ident number	0x156D				
Profile version	3.02				
Device description files (GSD, DTM, DD)	Information and files under: • www.endress.com • www.profibus.org				
Supported functions	 Identification & Maintenance Simplest device identification on the part of the control system and nameplate PROFIBUS upload/download Reading and writing parameters is up to ten times faster with PROFIBUS upload/download Condensed status Simplest and self-explanatory diagnostic information by categorizing diagnostic messages that occur 				
Configuration of the device address	 DIP switches on the I/O electronics module Local display Via operating tools (e.g. FieldCare) 				
Compatibility with earlier model	If the device is replaced, the measuring device Promass 300 supports the compatibility of the cyclic data with previous models. It is not necessary to adjust the engineering parameters of the PROFIBUS network with the Promass 300 GSD file.				
	Earlier models: Promass 80 PROFIBUS PA - ID No.: 1528 (hex) - Extended GSD file: EH3x1528.gsd - Standard GSD file: EH3_1528.gsd Promass 83 PROFIBUS PA - ID No.: 152A (hex) - Extended GSD file: EH3x152A.gsd - Standard GSD file: EH3_152A.gsd				
	Description of the function scope of compatibility: Operating Instructions $\rightarrow \square$ 120.				
System integration	 Information regarding system integration: Operating Instructions → ¹ 120. Cyclic data transmission Block model Description of the modules 				

PROFIBUS DP

Manufacturer ID	0x11
Ident number	0x156F
Profile version	3.02
Device description files (GSD, DTM, DD)	Information and files under: • www.endress.com On the product page for the device: Documents/Software → Device drivers • www.profibus.org
Supported functions	 Identification & Maintenance Simplest device identification on the part of the control system and nameplate PROFIBUS upload/download Reading and writing parameters is up to ten times faster with PROFIBUS upload/download Condensed status Simplest and self-explanatory diagnostic information by categorizing diagnostic messages that occur
Configuration of the device address	DIP switches on the I/O electronics moduleVia operating tools (e.g. FieldCare)

Compatibility with earlier model	If the device is replaced, the measuring device Promass 300 supports the compatibility of the cyclic data with previous models. It is not necessary to adjust the engineering parameters of the PROFIBUS network with the Promass 300 GSD file.
	Previous model: Promass 83 PROFIBUS DP – ID No.: 1529 (hex) – Extended GSD file: EH3x1529.gsd – Standard GSD file: EH3_1529.gsd
	Description of the function scope of compatibility: Operating Instructions $\rightarrow \textcircled{1}{20}$.
System integration	 Information regarding system integration: Operating Instructions → ¹ 120. Cyclic data transmission Block model Description of the modules

EtherNet/IP

Protocol	 The CIP Networks Library Volume 1: Common Industrial Protocol The CIP Networks Library Volume 2: EtherNet/IP Adaptation of CIP 				
Communication type	10Base-T100Base-TX				
Device profile	Generic device (product type: 0x2B)				
Manufacturer ID	0x11				
Device type ID	0x103B				
Baud rates	Automatic $^{10}\!\!\!\!/_{100}$ Mbit with half-duplex and full-duplex detection				
Polarity	Auto-polarity for automatic correction of crossed TxD and RxD pairs				
Supported CIP connections	Max. 3 connections				
Explicit connections	Max. 6 connections				
I/O connections	Max. 6 connections (scanner)				
Configuration options for measuring device	 DIP switches on the electronics module for IP addressing Manufacturer-specific software (FieldCare) Add-on Profile Level 3 for Rockwell Automation control systems Web browser Electronic Data Sheet (EDS) integrated in the measuring device 				
Configuration of the EtherNet interface	 Speed: 10 MBit, 100 MBit, auto (factory setting) Duplex: half-duplex, full-duplex, auto (factory setting) 				
Configuration of the device address	 DIP switches on the electronics module for IP addressing (last octet) DHCP Manufacturer-specific software (FieldCare) Add-on Profile Level 3 for Rockwell Automation control systems Web browser EtherNet/IP tools, e.g. RSLinx (Rockwell Automation) 				
Device Level Ring (DLR)	Yes				
System integration	Information regarding system integration: Operating Instructions $\rightarrow \cong 120.$				
	Cyclic data transmissionBlock modelInput and output groups				

PROFINET

Protocol	"Application layer protocol for decentral device periphery and distributed automation", version 2.3
Communication type	100 MBit/s

Conformity class	Conformance Class B				
Netload Class	Netload Class II				
Baud rates	Automatic 100 Mbit/s with full-duplex detection				
Cycle times	From 8 ms				
Polarity	Auto-polarity for automatic correction of crossed TxD and RxD pairs				
Media Redundancy Protocol (MRP)	Yes				
Device profile	Application interface identifier 0xF600 Generic device				
Manufacturer ID	0x11				
Device type ID	0x843B				
Device description files (GSD, DTM, DD)	Information and files under: • www.endress.com On the product page for the device: Documents/Software → Device drivers • www.profibus.org				
Supported connections	 1 x AR (IO Controller AR) 1 x AR (IO-Supervisor Device AR connection allowed) 1 x Input CR (Communication Relation) 1 x Output CR (Communication Relation) 1 x Alarm CR (Communication Relation) 				
Configuration options for measuring device	 DIP switches on the electronics module, for device name assignment (last part) Manufacturer-specific software (FieldCare, DeviceCare) Web browser Device master file (GSD), can be read out via the integrated Web server of the measuring device 				
Configuration of the device name	 DIP switches on the electronics module, for device name assignment (last part) DCP protocol Process Device Manager (PDM) Integrated Web server 				
Supported functions	 Identification & Maintenance Simple device identification via: Control system Nameplate Measured value status The process variables are communicated with a measured value status Blinking feature via the onsite display for simple device identification and assignment Device operation via operating tools (e.g. FieldCare, DeviceCare, SIMATIC PDM) 				
System integration	Information regarding system integration: Operating Instructions → 🗎 120 • Cyclic data transmission • Overview and description of the modules • Status coding • Startup configuration • Factory setting:				

FOUNDATION Fieldbus

Manufacturer ID	0x452B48 (hex)
Ident number	0x103B (hex)
Device revision	1
DD revision	Information and files under:
CFF revision	www.endress.comwww.fieldbus.org
Interoperability Test Kit (ITK)	Version 6.2.0

ITK Test Campaign Number	Information: • www.endress.com • www.fieldbus.org					
Link Master capability (LAS)	Yes					
Choice of "Link Master" and "Basic Device"	Yes Factory setting: Basic Device					
Node address	Factory setting: 247 (0xF7)					
Supported functions	The following methods are supported: Restart ENP Restart Diagnostic Set to OOS Set to AUTO Read trend data Read event logbook					
Virtual Communication Relation	nships (VCRs)					
Number of VCRs	44					
Number of link objects in VFD	50					
Permanent entries	1					
Client VCRs	0					
Server VCRs	10					
Source VCRs	43					
Sink VCRs	0					
Subscriber VCRs	43					
Publisher VCRs	43					
Device Link Capabilities						
Slot time	4					
Min. delay between PDU	8					
Max. response delay	16					
System integration	 Information regarding system integration: Operating Instructions → ^B 120. Cyclic data transmission Description of the modules Execution times Methods 					

Modbus RS485

Protocol	Modbus Applications Protocol Specification V1.1			
Response times	 Direct data access: typically 25 to 50 ms Auto-scan buffer (data range): typically 3 to 5 ms 			
Device type	Slave			
Slave address range	1 to 247			
Broadcast address range	0			
Function codes	 03: Read holding register 04: Read input register 06: Write single registers 08: Diagnostics 16: Write multiple registers 23: Read/write multiple registers 			
Broadcast messages	Supported by the following function codes: 06: Write single registers 16: Write multiple registers 23: Read/write multiple registers 			

Supported baud rate	 1 200 BAUD 2 400 BAUD 4 800 BAUD 9 600 BAUD 19 200 BAUD 38 400 BAUD 57 600 BAUD 115 200 BAUD
Data transfer mode	ASCIIRTU
Data access	Each device parameter can be accessed via Modbus RS485.
Compatibility with earlier model	If the device is replaced, the measuring device Promass 300 supports the compatibility of the Modbus registers for the process variables and the diagnostic information with the previous model Promass 83. It is not necessary to change the engineering parameters in the automation system.Image: Description of the function scope of compatibility:
System integration	 Information on system integration: Operating Instructions → Modbus RS485 information Function codes Register information Response time Modbus data map

Power supply

Terminal assignment

Transmitter: supply voltage, input/outputs

HART

Supply	voltage Input/output 1 Inp		ply voltage Input/output 1 Input/output 2		Input/output 3		
1 (+)	2 (-)	26 (+)	27 (-)	24 (+)	25 (-)	22 (+)	23 (-)
		The terminal assignment depends on the specific device version ordered \rightarrow 🗎 14.					

FOUNDATION Fieldbus

Supply	Supply voltage		Input/output 1		Input/output 2		Input/output 3	
1 (+)	2 (-)	26 (A)	27 (B)	24 (+)	25 (-)	22 (+)	23 (-)	
		The terminal assignment depends on the specific device version ordered \rightarrow 🗎 14.						

PROFIBUS PA

Supply voltage		Input/output 1		Input/output 2		Input/output 3		
1 (+)	2 (-)	26 (B)	27 (A)	24 (+)	25 (-)	22 (+)	23 (-)	
		The terminal assignment depends on the specific device version ordered $\rightarrow \square 14$.						

PROFIBUS DP

Supply	voltage	Input/output 1		Input/output 2		Input/output 3		
1 (+)	2 (-)	26 (B)	27 (A)	24 (+)	25 (-)	22 (+)	23 (-)	
		The terminal assignment depends on the specific device version ordered $\rightarrow \square 14$.						

Modbus RS485

Supply	voltage	Input/output 1		Input/output 2		Input/output 3		
1 (+)	2 (-)	26 (B)	27 (A)	24 (+)	25 (-)	22 (+)	23 (-)	
		The terminal assignment depends on the specific device version ordered $\rightarrow \square 14$.						

PROFINET

Supply	voltage	Input/output 1	Input/output 2		Input/output 3	
1 (+)	2 (-)	PROFINET (RJ45 connector)		5	22 (+) t depends on t rdered → 🗎 1	

EtherNet/IP

Supply	voltage	Input/output 1	Input/output 2		Input/output 3	
1 (+)	2 (-)	EtherNet/IP (RJ45 connector)		5	22 (+) t depends on t rdered → 🗎 1	*

Terminal assignment of the remote display and operating module $\rightarrow \cong$ 33.

Device plugs available

Device plugs may not be used in hazardous areas!

Device plugs for fieldbus systems:

Order code for "Input; output 1"

- Option SA "FOUNDATION Fieldbus" \rightarrow 🗎 28
- Option **GA** "PROFIBUS PA" \rightarrow 🗎 28
- Option **RA** "PROFINET" $\rightarrow \cong 29$
- Option NA "EtherNet/IP" $\rightarrow \cong 29$

Device plug for connecting to the service interface:

Order code for "Accessory mounted" option **NB**, adapter RJ45 M12 (service interface) $\rightarrow \cong 30$

Order code for "Input; output 1", option SA "FOUNDATION Fieldbus"

Order code for	Cable entry/connection $\rightarrow \cong 32$		
"Electrical connection"	2	3	
M, 3, 4, 5	7/8" connector	-	

Order code for "Input; output 1", option GA "PROFIBUS PA"

Order code for	Cable entry/connection $\rightarrow \cong 32$				
"Electrical connection"	2	3			
L, N, P, U	Connector M12 × 1	-			

Order code for "Input; output 1", option RA "PROFINET"

Order code for	Cable entry/connection $\rightarrow \triangleq 32$				
"Electrical connection"	2	3			
L, N, P, U	Connector M12 × 1	-			
R ^{1) 2)} , S ^{1) 2)} , T ^{1) 2)} , V ^{1) 2)}	Connector M12 × 1	Connector M12 × 1			

 Cannot be combined with an external WLAN antenna (order code for "Enclosed accessories", option P8) of an RJ45 M12 adapter for the service interface (order code for "Accessories mounted", option NB) or of the remote display and operating module DKX001.

2) Suitable for integrating the device in a ring topology.

Order code for "Input; output 1", option NA "EtherNet/IP"

Order code for	Cable entry/connection $\rightarrow \triangleq 32$			
"Electrical connection"	2	3		
L, N, P, U	Connector M12 × 1	-		
R ¹⁾²⁾ , S ¹⁾²⁾ , T ¹⁾²⁾ , V ¹⁾²⁾	Connector M12 × 1	Connector M12 × 1		

 Cannot be combined with an external WLAN antenna (order code for "Enclosed accessories", option P8) of an RJ45 M12 adapter for the service interface (order code for "Accessories mounted", option NB) or of the remote display and operating module DKX001

2) Suitable for integrating the device in a ring topology.

Order code for "Accessory mounted", option NB "Adapter RJ45 M12 (service interface)"

Order code	Cable entry/coupling $\rightarrow \square 32$				
"Accessory mounted"	Cable entry 2	Cable entry 3			
NB	Plug M12 × 1	-			

Pin assignment, device plug

FOUNDATION Fieldbus

	Pin		Assignment	Coding	Plug/socket
3	1	+	Signal +	А	Plug
/ 4	2	-	Signal –		
	3		Grounding		
	4		Not assigned		

PROFIBUS PA


Pin		Assignment	Coding	Plug/socket
1	+	PROFIBUS PA +	А	Plug
2		Grounding		
3	-	PROFIBUS PA -		
4		Not assigned		

PROFINET

2	Pin	Assignment		
	1	+	TD +	
	2	+	RD +	
	3	-	TD –	
	4	-	RD -	
4 A0032047	Cod	ling	Plug/socket	
	Ι)	Socket	

- Recommended plug: Binder, series 763, part no. 99 3729 810 04
 - Phoenix, part no. 1543223 SACC-M12MSD-4Q
 - When using the device in a hazardous location, use a suitably certified plug.

EtherNet/IP



Recommended plug:

- Binder, series 763, part no. 99 3729 810 04
- Phoenix, part no. 1543223 SACC-M12MSD-4Q
- When using the device in a hazardous location, use a suitably certified plug.

Service interface

Order code for "Accessories mounted", option NB: Adapter RJ45 M12 (service interface)

2	Pin	Assignment		
	1	+	Тх	
	2	+	Rx	
	3	-	Тх	
	4	-	Rx	
4 A0032047	Coding		Plug/socket	
	Ι)	Socket	

- Recommended plug: Binder, series 763, part no. 99 3729 810 04
 - Phoenix, part no. 1543223 SACC-M12MSD-4Q

• When using the device in a hazardous location, use a suitably certified plug.

Supply	voltage
--------	---------


Order code for "Power supply"	terminal voltage		Frequency range
Option D	DC24 V	±20%	-
Option E	AC100 to 240 V	-15+10%	50/60 Hz
Option I	DC24 V	±20%	-
	AC100 to 240 V	-15+10%	50/60 Hz

Power consumption	Transmitter					
	Max. 10 W (active power)					
	switch-on current	Max. 36 A (as per NAMUR Recommendation NE21)				
Current consumption	Transmitter					
	 Max. 400 mA (24 V) Max. 200 mA (110 V, 50/60 Hz; 230 V, 50/60 Hz) 					
Power supply failure	 Totalizers stop at the last value measured. Depending on the device version, the configuration is retained in the device memoryor in the pluggable data memory (HistoROM DAT). Error messages (incl. total operated hours) are stored. 					


Electrical connection

Connecting the transmitter

- Image: Terminal assignment → 27
- Device plugs available →
 [●] 28



- 1 Terminal connection for supply voltage
- 2 Terminal connection for signal transmission, input/output
- 3 Terminal connection for signal transmission, input/output or terminal for network connection via service interface (CDI-RJ45); Optional: terminal connection for external WLAN antenna or connection for remote display and operating module DKX001
- 4 Protective ground (PE)



Order code for "Accessories", option **NB**: "Adapter RJ45 M12 (service interface)" The adapter connects the service interface (CDI-RJ45) to an M12 connector mounted in the

cable entry. Therefore the connection to the service interface can be established via an M12 connector without opening the device.




Network connection via service interface (CDI-RJ45) \rightarrow \cong 106

Connecting in a ring topology

Device versions with EtherNet/IP and PROFINET communication protocols can be integrated into a ring topology. The device is integrated via the terminal connection for signal transmission (output 1) and the connection to the service interface (CDI-RJ45).

Integrate the transmitter into a ring topology:

- EtherNet/IP → 🖺 104
 - PROFINET \rightarrow 🗎 105




- 1 Terminal connection for supply voltage
- 2 Terminal connection for signal transmission: PROFINET or EtherNet/IP (RJ45 connector)
- *3 Connection to service interface (CDI-RJ45)*
- 4 Protective earth (PE)

If the device has additional input/outputs, these are routed via the cable entry for the connection to the service interface (CDI-RJ45).

Connecting the remote display and operating module DKX001

The remote display and operating module DKX001 is available as an optional extra → 🗎 117.


- The remote display and operating module DKX001 is only available for the following housing versions, order code for "Housing":
 - Option A "Aluminum, coated"
 - Option L "Cast, stainless"
- The measuring device is always supplied with a dummy cover when the remote display and operating module DKX001 is ordered directly with the measuring device. Display or operation at the transmitter is not possible in this case.
- If ordered subsequently, the remote display and operating module DKX001 may not be connected at the same time as the existing measuring device display module. Only one display or operation unit may be connected to the transmitter at any one time.



- 1 Remote display and operating module DKX001
- 2 Protective earth (PE)
- 3 Connecting cable
- 4 Measuring device
- 5 Protective earth (PE)


Connection examples

Current output 4 to 20 mA HART



2 Connection example for 4 to 20 mA HART current output (active)


- *1* Automation system with current input (e.g. PLC)
- 2 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications $\rightarrow \cong 41$
- *3* Connection for HART operating devices $\rightarrow \cong 101$
- 4 Resistor for HART communication ($\geq 250 \Omega$): observe maximum load $\rightarrow \cong 15$
- 5 Analog display unit: observe maximum load $\rightarrow \square 15$
- 6 Transmitter



☑ 3 Connection example for 4 to 20 mA HART current output (passive)


- 1 Automation system with current input (e.g. PLC)
- 2 Power supply
- 3 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications $\rightarrow \square 41$
- 4 Analog display unit: observe maximum load $\rightarrow \equiv 15$
- 5 Transmitter

HART input



- Connection example for HART input with a common negative (passive)
- 1 Automation system with HART output (e.g. PLC)
- 2 Active barrier for power supply (e.g. RN221N)
- 3 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 Analog display unit: observe maximum load
- 5 Pressure transmitter (e.g. Cerabar M, Cerabar S): see requirements
- 6 Transmitter

PROFIBUS PA




- ☑ 5 Connection example for PROFIBUS PA
 - Control system (e.g. PLC)
- 2 PROFIBUS PA segment coupler
- 3 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 T-box

1

- 5 Measuring device
- 6 Local grounding
- 7 Bus terminator
- 8 Potential matching line

PROFIBUS DP




Connection example for PROFIBUS DP, non-hazardous area and Zone 2/Div. 2

- 1 Control system (e.g. PLC)
- 2 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 3 Distribution box
- 4 Transmitter


If baud rates > 1.5 MBaud an EMC cable entry must be used and the cable shield must continue as far as the terminal wherever possible.

EtherNet/IP




- 1 Control system (e.g. PLC)
- 2 Ethernet switch
- *3 Observe cable specifications*
- 4 Device plug
- 5 Transmitter

EtherNet/IP: DLR (Device Level Ring)



- 1 Control system (e.g. PLC)
- 2 Ethernet switch
- *3 Observe cable specifications* $\rightarrow \triangleq 41$
- 4 Connecting cable between the two transmitters
- 5 Transmitter


PROFINET



8 Connection example for PROFINET


- 1 Control system (e.g. PLC)
- 2 Ethernet switch
- 3 Observe cable specifications
- 4 Device plug
- 5 Transmitter

PROFINET: MRP (Media Redundancy Protocol)



- 1 Control system (e.g. PLC)
- 2 Ethernet switch
- 3 Observe cable specifications $\rightarrow \triangleq 41$
- 4 Connecting cable between the two transmitters
- 5 Transmitter


FOUNDATION Fieldbus



Connection example for FOUNDATION Fieldbus

- 1 Control system (e.g. PLC)
- 2 Power Conditioner (FOUNDATION Fieldbus)
- 3 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 T-box
- 5 Measuring device
- 6 Local grounding
- 7 Bus terminator
- 8 Potential matching line


Modbus RS485



In Connection example for Modbus RS485, non-hazardous area and Zone 2; Class I, Division 2


- 1 Control system (e.g. PLC)
- 2 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 3 Distribution box
- 4 Transmitter

Current output 4-20 mA



■ 11 Connection example for 4-20 mA current output (active)


- 1 Automation system with current input (e.g. PLC)
- 2 Analog display unit: observe maximum load
- 3 Transmitter



■ 12 Connection example for 4-20 mA current output (passive)

- 1 Automation system with current input (e.g. PLC)
- 2 Active barrier for power supply (e.g. RN221N)
- 3 Analog display unit: observe maximum load
- 4 Transmitter


Pulse/frequency output



■ 13 Connection example for pulse/frequency output (passive)

- 1 Automation system with pulse/frequency input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: Observe input values $\rightarrow \square 16$


Switch output



14 Connection example for switch output (passive)


- 1 Automation system with switch input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: Observe input values $\rightarrow \square 16$


Double pulse output



■ 15 Connection example for double pulse output (active)


- 1 Automation system with double pulse input (e.g. PLC)
- 2 Transmitter: Observe input values $\rightarrow \square 18$
- 3 Double pulse output
- 4 Double pulse output (slave), phase-shifted





- 1 Automation system with double pulse input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: Observe input values $\rightarrow \square 18$
- 4 Double pulse output
- 5 Double pulse output (slave), phase-shifted


Relay output



■ 17 Connection example for relay output (passive)

- 1 Automation system with relay input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: Observe input values $\rightarrow \square 18$

Current input



■ 18 Connection example for 4 to 20 mA current input

- 1 Power supply
- 2 Terminal box
- 3 External measuring device (for reading in pressure or temperature, for instance)
- 4 Transmitter

Status input

	Image: Automation system with status output (e.g. PLC) Image: Provide the system wi
Potential equalization	Requirements
r otentiar equalization	No special measures for potential equalization are required.
	Please consider the following to ensure correct measurement:
	 Same electrical potential for the fluid and sensor
	 Company-internal grounding concepts
terminals	Spring-loaded terminals: Suitable for strands and strands with ferrules.
	Conductor cross-section 0.2 to 2.5 mm^2 (24 to 12 AWG).
Cable entries	 Cable gland: M20 × 1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in) Thread for cable entry: NPT ½" G ½" M20 Device plug for digital communication: M12 Only available for certain device versions → 🖺 28.
Cable specification	Permitted temperature range
	The installation guidelines that apply in the country of installation must be observed.The cables must be suitable for the minimum and maximum temperatures to be expected.
	Power supply cable
	Standard installation cable is sufficient.
	Signal cable
	Current output 4 to 20 mA HART
	A shielded cable is recommended. Observe grounding concept of the plant.
	PROFIBUS PA
	Twisted, shielded two-wire cable. Cable type A is recommended .
	For further information on planning and installing PROFIBUS networks see:
	 Operating Instructions "PROFIBUS DP/PA: Guidelines for planning and commissioning"
	 (BA00034S) PNO Directive 2.092 "PROFIBUS PA User and Installation Guideline" IEC 61158-2 (MBP)
	PROFIBUS DP
	The IEC 61158 standard specifies two types of cable (A and B) for the bus line which can be used for every transmission rate. Cable type A is recommended.

Cable type	A			
Characteristic impedance	135 to 165 Ω at a measuring frequency of 3 to 20 MHz			
Cable capacitance	< 30 pF/m			
Wire cross-section	> 0.34 mm ² (22 AWG)			
Cable type	Twisted pairs			
Loop resistance	<110 Ω/km			
Signal damping	Max. 9 dB over the entire length of the cable cross-section			
Shield	Copper braided shielding or braided shielding with foil shield. When grounding the cable shield, observe the grounding concept of the plant.			

For further information on planning and installing PROFIBUS networks see:

- Operating Instructions "PROFIBUS DP/PA: Guidelines for planning and commissioning" (BA00034S)
- PNO Directive 2.092 "PROFIBUS PA User and Installation Guideline"
- IEC 61158-2 (MBP)

EtherNet/IP

The standard ANSI/TIA/EIA-568-B.2 Annex specifies CAT 5 as the minimum category for a cable used for EtherNet/IP. CAT 5e and CAT 6 are recommended.

For more information on planning and installing EtherNet/IP networks, please refer to the "Media Planning and Installation Manual. EtherNet/IP" of ODVA Organization

PROFINET

Standard IEC 61156-6 specifies CAT 5 as the minimum category for a cable used for PROFINET. CAT 5e and CAT 6 are recommended.

For more information on planning and installing PROFINET networks, see: "PROFINET Cabling and Interconnection Technology", Guideline for PROFINET

FOUNDATION Fieldbus

Twisted, shielded two-wire cable.

For further information on planning and installing FOUNDATION Fieldbus networks see:

- Operating Instructions for "FOUNDATION Fieldbus Overview" (BA00013S)
- FOUNDATION Fieldbus Guideline
- IEC 61158-2 (MBP)

Modbus RS485

The EIA/TIA-485 standard specifies two types of cable (A and B) for the bus line which can be used for every transmission rate. Cable type A is recommended.

Cable type	A			
Characteristic impedance	apedance 135 to 165 Ω at a measuring frequency of 3 to 20 MHz			
Cable capacitance	< 30 pF/m			
Wire cross-section	> 0.34 mm ² (22 AWG)			
Cable type	Twisted pairs			
Loop resistance	<110 Ω/km			
Signal damping	Max. 9 dB over the entire length of the cable cross-section			
Shield	Copper braided shielding or braided shielding with foil shield. When grounding the cable shield, observe the grounding concept of the plant.			

Current output 0/4 to 20 mA

Standard installation cable is sufficient.

Pulse/frequency/switch output Standard installation cable is sufficient.

Double pulse output

Standard installation cable is sufficient.

Relay output Standard installation cable is sufficient.

Current input 0/4 to 20 mA Standard installation cable is sufficient.

Status input Standard installation cable is sufficient.

Connecting cable for transmitter - remote display and operating module DKX001

Standard cable

A standard cable can be used as the connecting cable.

Standard cable	4 cores (2 pairs); pair-stranded with common shield	
Shielding	Tin-plated copper-braid, optical cover \ge 85 %	
Capacitance: core/shield	Maximum 1 000 nF for Zone 1; Class I, Division 1	
L/R	Maximum 24 $\mu H/\Omega$ for Zone 1; Class I, Division 1	
Cable length Maximum 300 m (1000 ft), see the following table		

Cross-section	Cable length for use in: Non-hazardous area Hazardous area: Zone 2; Class I, Division 2 Hazardous area: Zone 1; Class I, Division 1
0.34 mm ² (22 AWG)	80 m (270 ft)
0.50 mm ² (20 AWG)	120 m (400 ft)
0.75 mm ² (18 AWG)	180 m (600 ft)
1.00 mm ² (17 AWG)	240 m (800 ft)
1.50 mm ² (15 AWG)	300 m (1000 ft)

Optionally available connecting cable

Standard cable	$2\times2\times0.34~mm^2$ (22 AWG) PVC cable $^{1)}$ with common shield (2 pairs, pairstranded)		
Flame resistance	According to DIN EN 60332-1-2		
Oil-resistance	According to DIN EN 60811-2-1		
Shielding	Tin-plated copper-braid, optical cover \ge 85 %		
Capacitance: core/shield	<200 pF/m		
L/R	<24 μH/Ω		
Available cable length	10 m (35 ft)		
Operating temperature	When mounted in a fixed position: –50 to +105 $^\circ$ C (–58 to +221 $^\circ$ F); when cable can move freely: –25 to +105 $^\circ$ C (–13 to +221 $^\circ$ F)		

1) UV radiation can impair the cable outer sheath. Protect the cable from direct sunshine where possible.

Reference operating	 Error limits based on ISO 1163. 	1				
conditions	• Water with $+15$ to $+45$ °C (+59 to $+113$ °F) at2 to 6 bar (29 to 87 psi)					
	 Specifications as per calibration protocol 					
	 Accuracy based on accredited ca 	alibration rigs that are traced to IS	0 17025.			
	To obtain measured errors, u	use the <i>Applicator</i> sizing tool → 🗎	119			
Maximum measured error	o.r. = of reading; $1 \text{ g/cm}^3 = 1 \text{ kg/l}$; T = medium temperature				
	Base accuracy					
	Design fundamentals → 🗎 4	48				
	Mass flow and volume flow (liquids)					
	± 0.05 % o.r. (PremiumCal; order code for "Calibration flow", option D, for mass flow) ± 0.10 % o.r.					
	Mass flow (cryogenic liquids)					
	Order code for "Measuring tube material", option LA					
	±0.35 % o.r.					
	Mass flow (gases)					
	±0.35 % o.r.					
	Density (liquids)					
	Under reference operating conditions	Standard density calibration ¹⁾	Wide-range Density specification ^{2) 3)}			
	[g/cm ³]	[g/cm ³]	[g/cm ³]			
	<u>±0.0005</u> ±0.01 ±0.001					

Performance characteristics

Valid over the entire temperature and density range 1)

2) 3)

Valid range for special density calibration: 0 to 2 g/cm³, +5 to +80 °C (+41 to +176 °F) Order code for "Application package", option EE "Special density" only in combination with the order code for "Measuring tube mat., wetted surface", option BB, BF, HA, SA

Density (cryogenic liquids)

Order code for "Measuring tube material", option LA

 $\pm 0.05 \text{ g/cm}^3$

Temperature

 $\pm 0.5 \ ^{\circ}C \pm 0.005 \cdot T \ ^{\circ}C \ (\pm 0.9 \ ^{\circ}F \pm 0.003 \cdot (T - 32) \ ^{\circ}F)$

Zero point stability

D	N	Zero point stability		
[mm] [in]		[kg/h]	[lb/min]	
8	3⁄8	0.030	0.001	
15	1/2	0.200	0.007	
25	1	0.540	0.019	
40	1½	2.25	0.083	
50	2	3.50	0.129	

D	N	Zero point stability		
[mm]	[in]	[kg/h]	[lb/min]	
80	3	9.0	0.330	
100	4	14.0	0.514	
150	6	32.0	1.17	
250	10	88.0	3.23	

High-temperature version: order code for "Measuring tube material", option TT, TU

D	N	Zero point stability		
[mm] [in]		[kg/h]	[lb/min]	
25	1	1.80	0.0661	
50	2	7.00	0.2572	
80	3	18.0	0.6610	

For devices with low-temperature version, order code for "Measuring tube mat., wetted surface", option LA, please note the following:

NOTICE

Zero point confirmation and zero point adjustment are difficult to carry out in the field due to the vaporization of the cryogenic liquid.

► As a general rule, the factory-set zero point should not be changed. Please ensure that the medium is in the liquid phase if a zero point adjustment is to be carried out.

Flow values

Flow values as turndown parameter depending on nominal diameter.

SI units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[mm]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]
8	2 000	200	100	40	20	4
15	6 500	650	325	130	65	13
25	18000	1800	900	360	180	36
40	45 000	4500	2250	900	450	90
50	70000	7 000	3 500	1400	700	140
80	180000	18000	9000	3 600	1800	360
100	350000	35000	17500	7 000	3 500	700
150	800000	80000	40000	16000	8000	1600
250	2 200 000	220000	110000	44000	22000	4 400

US units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[inch]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]
3/8	73.50	7.350	3.675	1.470	0.735	0.147
1/2	238.9	23.89	11.95	4.778	2.389	0.478
1	661.5	66.15	33.08	13.23	6.615	1.323
11/2	1654	165.4	82.70	33.08	16.54	3.308

DN	1:1	1:10	1:20	1:50	1:100	1:500
[inch]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]
2	2573	257.3	128.7	51.46	25.73	5.146
3	6615	661.5	330.8	132.3	66.15	13.23
4	12860	1286	643.0	257.2	128.6	25.72
6	29400	2940	1470	588	294	58.80
10	80850	8085	4043	1617	808.5	161.7

Accuracy of outputs

The outputs have the following base accuracy specifications.

Current output

Accuracy	±5 μA
----------	-------

Pulse/frequency output

o.r. = of reading

Accuracy

Max. ±50 ppm o.r. (over the entire ambient temperature range)

Repeatability

o.r. = of reading; $1 \text{ g/cm}^3 = 1 \text{ kg/l}$; T = medium temperature

Base repeatability

 $\square Design fundamentals \rightarrow \square 48$

Mass flow and volume flow (liquids) ±0.025 % o.r. (PremiumCal, for mass flow) ±0.05 % o.r.

Mass flow (cryogenic liquids) Order code for "Measuring tube material", option LA ± 0.175 % % o.r.

Mass flow (gases)

±0.25 % o.r.

Density (liquids) $\pm 0.00025 \text{ g/cm}^3$

Density (cryogenic liquids) Order code for "Measuring tube material", option LA $\pm 0.025~g/cm^3$

Temperature

±0.25 °C ± 0.0025 · T °C (±0.45 °F ± 0.0015 · (T-32) °F)

Response time	The response time depend	The response time depends on the configuration (damping).		
Influence of ambient temperature	Current output			
	Temperature coefficient	Max. 1 µA/°C		

Pulse/frequency output

	Temperature coefficient No additional effect. Included in accuracy.	
Influence of medium	Mass flow and volume flow	
temperature	o.f.s. = of full scale value	
	When there is a difference between the temperature for zero point adjustment and the process temperature, the additional measured error of the sensor is typically ± 0.0002 % o.f.s./°C (± 0.000 o. f.s./°F).	
	The effect is reduced if zero point adjustment is performed at process temperature.	
	Density When there is a difference between the density calibration temperature and the process temperature, the typical measured error of the sensor is $\pm 0.00005 \text{ g/cm}^3$ /°C ($\pm 0.000025 \text{ g/cm}^3$ /°F). Field density calibration is possible.	
	Wide-range density specification (special density calibration) If the process temperature is outside the valid range ($\Rightarrow \triangleq 44$) the measured error is ±0.00005 g/cm ³ /°C (±0.000025 g/cm ³ /°F)	
	$\begin{bmatrix} kg/m^3 \end{bmatrix}$	
	-80 0 80 160 240 320 400 480 560 640 [F]	

Field density calibration, for example at +20 $^\circ\!\!C$ (+68 $^\circ\!\!F$) Special density calibration 1

2

Temperature

8

15

±0.005 · T °C (± 0.005 · (T – 32) °F)

Influence of medium pressure	The table below shows the effect on accuracy of mass flow due to a difference between calibration pressure and process pressure.				
	o.r. = of reading	o.r. = of reading			
	 It is possible to compensate for the effect by: Reading in the current pressure measured value via the current input. Specifying a fixed value for the pressure in the device parameters. 				
	Operating Ins	tructions→ 🗎 1	20.		
	DN	1	[% o.r./bar]	[% o.r./psi]	
	[mm]	[in]	1		

3/8

1/2

no influence

no influence

A0027453

D	N	[% o.r./bar]	[% o.r./psi]
[mm]	[in]		
25	1	no influer	nce
40	1½	-0.003	-0.0002
50	2	-0.008	-0.0006
80	3	-0.009	-0.0006
100	4	-0.007	-0.0005
150	6	-0.009	-0.0006
250	10	-0.009	-0.0006

Design fundamentals

o.r. = of reading, o.f.s. = of full scale value

BaseAccu = base accuracy in % o.r., BaseRepeat = base repeatability in % o.r.

MeasValue = measured value; ZeroPoint = zero point stability


Calculation of the maximum measured error as a function of the flow rate

Flow rate	Maximum measured error in % o.r.
$\geq \frac{\text{ZeroPoint}}{\text{BaseAccu}} \cdot 100$	± BaseAccu
A0021332	CU11200A
< ZeroPoint BaseAccu · 100	$\pm \frac{\text{ZeroPoint}}{\text{MeasValue}} \cdot 100$
A0021333	A0021334

Calculation of the maximum repeatability as a function of the flow rate

Flow rate	Maximum repeatability in % o.r.
$\geq \frac{\frac{1}{2} \cdot \text{ZeroPoint}}{\text{BaseRepeat}} \cdot 100$	± BaseRepeat
A002	
$< \frac{\frac{1}{2} \cdot \text{ZeroPoint}}{\text{BaseRepeat}} \cdot 100$	$\pm \frac{1}{2} \cdot \frac{\text{ZeroPoint}}{\text{MeasValue}} \cdot 100$
A002	36 A0021337

Example for maximum measured error




E Maximum measured error in % o.r. (example with PremiumCal)

Q Flow rate in % of maximum full scale value

Installation

No special measures such as supports etc. are necessary. External forces are absorbed by the construction of the device.

Mounting location




To prevent measuring errors arising from accumulation of gas bubbles in the measuring tube, avoid the following mounting locations in the pipe:

- Highest point of a pipeline.
- Directly upstream of a free pipe outlet in a down pipe.

Installation in down pipes

However, the following installation suggestion allows for installation in an open vertical pipeline. Pipe restrictions or the use of an orifice with a smaller cross-section than the nominal diameter prevent the sensor running empty while measurement is in progress.



20 Installation in a down pipe (e.g. for batching applications)

- 1 Supply tank
- Sensor
- 2 3 Orifice plate, pipe restriction
- 4 Valve 5
- Batching tank

D	N	Ø orifice plate, pipe restriction		
[mm]	[in]	[mm]	[in]	
8	3⁄8	6	0.24	
15	1/2	10	0.40	
25	1	14	0.55	
40	1½	22	0.87	
50	2	28	1.10	
80	3	50	1.97	
100	4	65	2.60	

D	N	Ø orifice plate,	pipe restriction
[mm]	[in]	[mm]	[in]
150	6	90	3.54
250	10	150	5.91

Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).


	Orientation		
A	Vertical orientation	A0015591	V V ¹⁾
В	Horizontal orientation, transmitter at top	A0015589	Exceptions: $\rightarrow \blacksquare 21, \cong 50$
С	Horizontal orientation, transmitter at bottom	A0015590	Exceptions: $\rightarrow \square 21, \square 50$
D	Horizontal orientation, transmitter at side	A0015592	×

1) This orientation is recommended to ensure self-draining.

2) Applications with low process temperatures may decrease the ambient temperature. To maintain the minimum ambient temperature for the transmitter, this orientation is recommended.

3) Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.

If a sensor is installed horizontally with a curved measuring tube, match the position of the sensor to the fluid properties.



■ 21 Orientation of sensor with curved measuring tube

1

2

Avoid this orientation for fluids with entrained solids: Risk of solids accumulating.

Avoid this orientation for outgassing fluids: Risk of gas accumulating.

Inlet and outlet runsNo special precautions need to be taken for fittings which create turbulence, such as valves, elbows
or T-pieces, as long as no cavitation occurs $\rightarrow \cong 60$.

Special mounting instructions

Drainability The measuring tubes can be completely drained and protected against solids build-up in vertical orientation.

Rupture disk

Information that is relevant to the process: $\rightarrow \cong 60$.

WARNING

Danger from medium escaping!

Medium escaping under pressure can cause injury or material damage.


- Take precautions to prevent danger to persons and damage if the rupture disk is actuated.
- Observe information on the rupture disk sticker.
- Make sure that the function and operation of the rupture disk is not impeded through the installation of the device.
- Do not use a heating jacket.
- Do not remove or damage the rupture disk.

The position of the rupture disk is indicated on a sticker beside it.

The transportation guard must be removed.

The existing connecting nozzles are not intended for the purpose of rinsing or pressure monitoring, but instead serve as the mounting location for the rupture disk.

In the event of a failure of the rupture disk, a discharge device can be screwed onto the internal thread of the rupture disk in order to drain off any escaping medium.



- 1 Rupture disk label
- 2 Rupture disk with 1/2" NPT internal thread with 1" width across flat
- 3 Transport protection

For information on the dimensions: see the "Mechanical construction" section (accessories)

Zero point adjustment

All measuring devices are calibrated in accordance with state-of-the-art technology. Calibration takes place under reference conditions $\rightarrow \textcircled{B}$ 44. Therefore, a zero point adjustment in the field is generally not required.

Experience shows that zero point adjustment is advisable only in special cases:

- To achieve maximum measuring accuracy even with low flow rates.
- Under extreme process or operating conditions (e.g. very high process temperatures or very high-viscosity fluids).

Ambient temperature range	Managering Jandar	$-40 \pm 160\% (1.40 \pm 140\%)$		
randicat temperature range	Measuring device	 -40 to +60 °C (-40 to +140 °F) Order code for "Test, certificate", option JP: -50 to +60 °C (-58 to +140 °F) 		
	Readability of the local display	-20 to +60 $^\circ$ C (-4 to +140 $^\circ$ F) The readability of the display may be impaired at temperatures outside the temperature range.		
	Dependency of am	bient temperature on medium temperature→ 🗎 53		
	 If operating outdoors: Avoid direct sunlight, particularly in warm climatic regions. 			
	You can order a we	eather protection cover from Endress+Hauser. $\rightarrow \triangleq 117$.		
Storage temperature	–50 to +80 °C (–58 to +	176 °F)		
Climate class	DIN EN 60068-2-38 (te	st Z/AD)		
Degree of protection	 Measuring device As standard: IP66/67, type 4X enclosure When housing is open: IP20, type 1 enclosure Display module: IP20, type 1 enclosure With the order code for "Sensor options", option CM: IP69 can also be ordered 			
External WLAN anten IP67		na		
Vibration resistance	 Oscillation, sinusoidal, following IEC 60068-2-6 2 to 8.4 Hz, 3.5 mm peak 8.4 to 2000 Hz, 1 g peak Oscillation, broadband noise following IEC 60068-2-64 10 to 200 Hz, 0.003 g²/Hz 200 to 2 000 Hz, 0.001 g²/Hz Total: 1.54 g rms 			
Shock resistance	Shock, half-sine according to IEC 60068-2-27 6 ms 50 g			
Shock resistance	Shock due to rough han	dling following IEC 60068-2-31		
Interior cleaning	 Cleaning in place (CIP) Sterilization in place (SIP) Options Oil- and grease-free version for wetted parts, without declaration Order code for "Service", option HA Oil- and grease-free version for wetted parts as per IEC/TR 60877-2.0 and BOC 50000810-4, with declaration Order code for "Service", option HB 			
Electromagnetic compatibility (EMC)	 As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21) Device version with PROFIBUS DP: Complies with emission limits for industry as per EN Volume 2, IEC 61784 The following applies for PROFIBUS DP: If baud rates > 1.5 MBaud, an EMC cable emused and the cable shield must continue as far as the terminal wherever possible. Details are provided in the Declaration of Conformity. 			


Environment

Process

Medium temperature range

Standard version	–50 to +150 °C (–58 to +302 °F)	Order code for "Measuring tube mat., wetted surface", option HA, SA, SB, SC
Extended temperature version	-50 to +240 °C (-58 to +464 °F)	Order code for "Measuring tube mat., wetted surface", option SD, SE, SF, TH
High-temperature version	–50 to +350 °C (–58 to +662 °F)	For nominal diameters DN 25 (1"), DN 50 (2") and DN 80 (3") Order code for "Measuring tube mat., wetted surface", option TT, TU
Low-temperature version	-196 to +150 °C (-320 to +302 °F)	Order code for "Measuring tube mat., wetted surface", option LA
	 Material fatigue due to excessive temperature difference! Maximum temperature difference of media used: 300 K 	

Dependency of ambient temperature on medium temperature



■ 22 Exemplary representation, values in the table below.

- *T_a Ambient temperature*
- T_m Medium temperature
- A Maximum permitted medium temperature T_m at $T_{a max} = 60 \degree C$ (140 °F); higher medium temperatures T_m require a reduced ambient temperature T_a
- *B* Maximum permitted ambient temperature T_a for the maximum specified medium temperature T_m of the sensor



Values for devices used in the hazardous area: Separate Ex documentation (XA) for the device \rightarrow 🗎 120.

	Not insulated				Insulated				
	Α		B		A		В		
Version	Ta	T _m	Ta	T _m	Ta	T _m	T _a	T _m	
Standard version	60 ℃ (140 ℉)	150 °C (302 °F)	-	-	60 °C (140 °F)	110 °C (230 °F)	55 ℃ (131 ℉)	150 ℃ (302 ℉)	
Extended temperature version	60 °C (140 °F)	170 ℃ (338 ℉)	55 ℃ (131 ℉)	240 ℃ (464 ℉)	60 °C (140 °F)	110 ℃ (230 ℉)	50 ℃ (122 ℉)	240 ℃ (464 ℉)	
High-temperature version	60 ℃ (140 ℉)	350 ℃ (662 ℉)	-	-	60 °C (140 °F)	350 °C (662 °F)	_	-	

Density


0 to 5000 kg/m^3 (0 to 312 lb/cf)

Pressure-temperature curves

The following pressure/temperature diagrams apply to all pressure-bearing parts of the device and not just the process connection. The diagrams show the maximum permissible medium pressure depending on the specific medium temperature.


- Pressure-temperature curves with temperature range +151 to +240 °C (+304 to +464 °F) exclusively for extended temperature version of measuring devices.
 - Pressure-temperature curves with temperature range +241 to +350 °C (+466 to +662 °F) exclusively for high temperature version of measuring devices.
 - Pressure-temperature curves with temperature range –196 to +150 °C (–320 to +302 °F) exclusively for low temperature version of measuring devices.

Flange according to EN 1092-1 (DIN 2501)




■ 23 With flange material 1.4404 (F316/F316L), Alloy C22

Flange according to ASME B16.5




■ 24 With flange material 1.4404 (F316/F316L)





■ 25 With flange material Alloy C22

Flange JIS B2220




🖻 26 With flange material 1.4404 (F316/F316L), Alloy C22







■ 27 With connection material 1.4404 (316/316L)

Lap joint flange according to EN 1092-1 (DIN 2501)




■ 28 With flange material 1.4301 (F304); wetted parts Alloy C22






29 With flange material 1.4301 (F304); wetted parts Alloy C22

Lap joint flange JIS B2220



■ 30 With flange material 1.4301 (F304); wetted parts Alloy C22


Thread DIN 11851




☑ 31 With connection material 1.4404 (316/316L)


DIN 11851 allows for applications up to +140 $^{\circ}$ C (+284 $^{\circ}$ F) if suitable sealing materials are used. Please take this into account when selecting seals and counterparts, as these components can limit the pressure and temperature range.

Thread DIN 11864-1 Form A




■ 32 With connection material 1.4404 (316/316L)





■ 33 With connection material 1.4404 (316/316L)




Thread SMS 1145

■ 34 With connection material 1.4404 (316/316L)


SMS 1145 allows for applications up to 16 bar (232 psi) if suitable sealing materials are used. Please take this into account when selecting seals and counterparts, as these components can limit the pressure and temperature range.

VCO



■ 35 With connection material 1.4404 (316/316L)

Tri-Clamp



The clamp connections are suitable up to a maximum pressure of 16 bar (232 psi). Please observe the operating limits of the clamp and seal used as they can be over 16 bar (232 psi). The clamp and seal are not included in the scope of supply.

Sensor housing

For standard versions with the temperature range -50 to +150 °C (-58 to +302 °F), the sensor housing is filled with dry nitrogen gas and protects the electronics and mechanics inside.

For all other temperature versions the sensor housing is filled with dry inert gas.

If a measuring tube fails (e.g. due to process characteristics like corrosive or abrasive fluids), the fluid will initially be contained by the sensor housing.

In the event of a tube failure, the pressure level inside the sensor housing will rise according to the operating process pressure. If the user judges that the sensor housing pressure rating/burst pressure does not provide an adequate safety margin, the device can be fitted with a rupture disk. This prevents excessively high pressure from forming inside the sensor housing. Therefore, the use of a rupture disk is strongly recommended in applications involving high gas pressures, and particularly in applications in which the process pressure is greater than 2/3 of the sensor housing burst pressure.

If there is a need to drain the leaking medium into a discharge device, the sensor should be fitted with a rupture disk. Connect the discharge to the additional threaded connection $\rightarrow \cong 82$.

If the sensor is to be purged with gas (gas detection), it should be equipped with purge connections.

Do not open the purge connections unless the containment can be filled immediately with a dry, inert gas. Use only low pressure to purge. Maximum pressure: 5 bar (72.5 psi).

Sensor housing nominal pressure rating and burst pressure

The following sensor housing nominal pressure ratings/burst pressures are only valid for standard devices and/or devices equipped with closed purge connections (not opened/as delivered).

If a device fitted with purge connections (order code for "Sensor option", option CH "Purge connection") is connected to the purge system, the maximum nominal pressure is determined by the purge system itself or by the device, depending on which component has the lower nominal pressure classification.

If the device is fitted with a rupture disk (order code for "Sensor option", option CA "Rupture disk"), the rupture disk trigger pressure is decisive for the maximum nominal pressure .

The sensor housing burst pressure refers to a typical internal pressure which is reached prior to mechanical failure of the sensor housing and which was determined during type testing. The corresponding type test declaration can be ordered with the device (order code for "Additional approval", option LN "Sensor housing burst pressure, type test").


D	N	pres (designed with	ing nominal sure a safety factor 4)	Sensor housing	burst pressure	
[mm]	[in]	[bar] [psi]		[bar]	[psi]	
8	3/8	40	580	255	3 698	
15	1/2	40	580	200	2 900	
25	1	40	580	280	4060	
40	11/2	40	580	180	2610	
50	2	40	580	195	2828	
80	3	25	362	105	1522	
100	4	16	232	85	1232	
150	6	16	232	80	1160	
250	10	10	145	57	826	

For information on the dimensions: see the "Mechanical construction" section

Rupture disk To increase the level of safety, a device version with a rupture disk with a trigger pressure of 10 to 15 bar (145 to 217.5 psi)can be used (order code for "Sensor option", option CA "rupture disk"). The use of rupture disks cannot be combined with the separately available heating jacket. Information on the dimensions of the rupture disk: $\rightarrow \cong 82$ Flow limit Select the nominal diameter by optimizing between the required flow range and permissible pressure loss. For an overview of the full scale values for the measuring range, see the "Measuring range" section $\rightarrow \square 11$ • The minimum recommended full scale value is approx. 1/20 of the maximum full scale value • In most applications, 20 to 50 % of the maximum full scale value can be considered ideal • A low full scale value must be selected for abrasive media (such as liquids with entrained solids): flow velocity < 1 m/s (< 3 ft/s). • For gas measurement the following rules apply: - The flow velocity in the measuring tubes should not exceed half the sound velocity (0.5 Mach). - The maximum mass flow depends on the density of the gas: formula $\rightarrow \square 11$ To calculate the flow limit, use the *Applicator* sizing tool $\rightarrow \square$ 119 4 Pressure loss To calculate the pressure loss, use the *Applicator* sizing tool \rightarrow \cong 119 + Promass F with reduced pressure loss: order code for "Sensor option", option CE "Reduced pressure loss" System pressure It is important that cavitation does not occur, or that gases entrained in the liquids do not outgas. This is prevented by means of a sufficiently high system pressure.

For this reason, the following mounting locations are recommended:

- At the lowest point in a vertical pipe
- Downstream from pumps (no danger of vacuum)



Thermal insulation

In the case of some fluids, it is important to keep the heat radiated from the sensor to the transmitter to a low level. A wide range of materials can be used for the required insulation.


The following device versions are recommended for versions with thermal insulation:

- Version with extended neck for insulation:
- Order code for "Sensor option", option CG with an extended neck length of 105 mm (4.13 in). Extended temperature version:
- Order code for "Measuring tube material", option SD, SE, SF or TH with an extended neck length of 105 mm (4.13 in).
- High-temperature version: Order code for "Measuring tube material", option TT or TU with an extended neck length of 142 mm (5.59 in).


NOTICE

Electronics overheating on account of thermal insulation!

- Recommended orientation: horizontal orientation, transmitter housing pointing downwards.
- Do not insulate the transmitter housing .
- ▶ Maximum permissible temperature at the lower end of the transmitter housing: 80 °C (176 °F)
- Thermal insulation with extended neck free: We recommend that you do not insulate the extended neck in order to ensure optimum dissipation of heat.



36 Thermal insulation with extended neck free




Heating

Some fluids require suitable measures to avoid loss of heat at the sensor.

Heating options

- Electrical heating, e.g. with electric band heaters
- Via pipes carrying hot water or steam
- Via heating jackets



NOTICE

Danger of overheating when heating

- ► Ensure that the temperature at the lower end of the transmitter housing does not exceed 80 °C (176 °F).
- Ensure that sufficient convection takes place at the transmitter neck.
- ► Ensure that a sufficiently large area of the transmitted neck remains exposed. The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.
- ► If using in potentially explosive atmospheres, observe the information in the device-specific Ex documentation. For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.

Vibrations

The high oscillation frequency of the measuring tubes ensures that the correct operation of the measuring system is not influenced by plant vibrations.

Custody transfer measurement

The measuring device is optionally tested in accordance with OIML R117/R81 and has an EU type evaluation certificate which authorizes the use in EU type-examination certificates according to Measuring Instruments Directive 2014/32/EU for service subject to legal metrological control ("custody transfer") for liquids other than water and cryogenic liquids (Annex VII).

The permitted fluid temperature in these applications is -200 to +90 °C (-328 to +194 °F).

The measuring device is optionally tested in accordance with OIML R137 and has an EU typeexamination certificate according to Measuring Instruments Directive 2014/32/EU for service as a gas meter subject to legal metrological control ("custody transfer") (Annex IV). The permitted fluid temperature in these applications is -25 to +55 °C (-13 to +131 °F).

The device is used with a legally controlled totalizer on the local display and optionally with legally controlled outputs.


Measuring devices subject to legal metrological control totalize in both directions, i.e. all the outputs consider flow components in the positive (forward) and negative (reverse) flow direction.

Generally a measuring device subject to legal metrological control is secured against tampering by seals on the transmitter or sensor. These seals may normally only be opened by a representative of the competent authority for legal metrology controls.


After putting the device into circulation or after sealing the device, operation is only possible to a limited extent.

Detailed ordering information is available from your local Endress+Hauser sales center for national approvals, which are based on the OIML certificates, for applications with liquids other than water, cryogenic liquids or gases.

Mechanical construction



Compact version



Order code for "Housing", option A "Aluminum, coated"

DN	A 1)	B 1)	С	D	E ²⁾³⁾	F ²⁾³⁾	G ⁴⁾	Н	I ⁴⁾	К	L	М
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
8	169	68	101	75	259.5	334.5	200	59	141	5.35	5)	70
15	169	68	101	75	259.5	334.5	200	59	141	8.30	5)	70
25	169	68	101	75	259.5	334.5	200	59	141	12.0	5)	70
40	169	68	101	105	264.5	369.5	200	59	141	17.6	5)	79
50	169	68	101	141	274.5	415.5	200	59	141	26.0	5)	99
80	169	68	101	200	294.5	494.5	200	59	141	40.5	5)	139
100	169	68	101	254	312.5	566.5	200	59	141	51.2	5)	176
150	169	68	101	378	333.5	711.5	200	59	141	68.9	5)	218
250	169	68	101	548	377.5	925.5	200	59	141	102.3	5)	305

1) Depending on the cable gland used: values up to + 30 mm

2) With order code for "Sensor option", option CG or order code for "Measuring tube material", option SD, SE, SF, TH, LA: values +70 mm

3) With order code for "Measuring tube material", option TT, TU: values +104 mm

4) For version without local display: values - 30 mm

5) Depends on the process connection in question

Order code for "Housing",	option A "Aluminum,	coated"; Ex d
---------------------------	---------------------	---------------

DN	A 1)	B 1)	С	D	E ²⁾³⁾	F	G ⁴⁾	Н	I ⁴⁾	К	L	М
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
8	188	85	103	75	290	365	217	58	148	5.35	5)	70
15	188	85	103	75	290	365	217	58	148	8.30	5)	70
25	188	85	103	75	290	365	217	58	148	12.0	5)	70
40	188	85	103	105	294.5	399.5	217	58	148	17.6	5)	79
50	188	85	103	141	304.5	445.5	217	58	148	26.0	5)	99
80	188	85	103	200	324.5	524.5	217	58	148	40.5	5)	139
100	188	85	103	254	342.5	596.5	217	58	148	51.2	5)	176

DN	A 1)	B 1)	С	D	E ²⁾³⁾	F	G ⁴⁾	Н	I ⁴⁾	К	L	М
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
150	188	85	103	378	363.5	741.5	217	58	148	68.9	5)	218
250	188	85	103	548	407.5	955.5	217	58	148	102.3	5)	305

1) Depending on the cable gland used: values up to + 30 mm

 With order code for "Sensor option", option CG or order code for "Measuring tube material", option SD, SE, SF, TH, LA: values +70 mm

3) With order code for "Measuring tube material", option TT, TU: values +104 mm

4) For version without local display: values - 49 mm

5) Depends on the process connection in question

Order code for "Housing", option B "Stainless, hygienic"

DN	A 1)	B 1)	С	D	E ²⁾³⁾	F	G ⁴⁾	Н	I ⁴⁾	К	L	М
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
8	183	73	110	75	259.5	334.5	207	65	142	5.35	5)	70
15	183	73	110	75	259.5	334.5	207	65	142	8.30	5)	70
25	183	73	110	75	259.5	334.5	207	65	142	12.0	5)	70
40	183	73	110	105	264.5	369.5	207	65	142	17.6	5)	79
50	183	73	110	141	274.5	415.5	207	65	142	26.0	5)	99
80	183	73	110	200	294.5	494.5	207	65	142	40.5	5)	139
100	183	73	110	254	312.5	566.5	207	65	142	51.2	5)	176
150	183	73	110	378	333.5	711.5	207	65	142	68.9	5)	218
250	183	73	110	548	377.5	925.5	207	65	142	102.3	5)	305

1) Depending on the cable gland used: values up to + 30 mm

2) With order code for "Sensor option", option CG or order code for "Measuring tube material", option SD, SE, SF, TH, LA: values +70 mm

3) With order code for "Measuring tube material", option TT, TU: values +104 mm

4) For version without local display: values - 13 mm

5) Depends on the process connection in question

Order code for "Housing", option L "Cast, stainless"

DN	A 1)	B 1)	С	D	E ²⁾³⁾	F	G	Н	I	К	L	М
[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
8	186	85	101	75	290	365	221	63	158	5.35	4)	70
15	186	85	101	75	290	365	221	63	158	8.30	4)	70
25	186	85	101	75	290	365	221	63	158	12.0	4)	70
40	186	85	101	105	294.5	399.5	221	63	158	17.6	4)	79
50	186	85	101	141	304.5	445.5	221	63	158	26.0	4)	99
80	186	85	101	200	324.5	524.5	221	63	158	40.5	4)	139
100	186	85	101	254	342.5	596.5	221	63	158	51.2	4)	176
150	186	85	101	378	363.5	741.5	221	63	158	68.9	4)	218
250	186	85	101	548	407.5	955.5	221	63	158	102.3	4)	305

1) Depending on the cable gland used: values up to + 30 mm


 With order code for "Sensor option", option CG or order code for "Measuring tube material", option SD, SE, SF, TH, LA: values +70 mm

3) With order code for "Measuring tube material", option TT, TU: values +104 mm

4) Depends on the process connection in question

Flange connections

Fixed flange EN 1092-1, ASME B16.5, JIS B2220



Length tolerance for dimension L in mm:

- DN ≤ 100: +1.5 / -2.0
- DN ≥ 125: +3.5

Flange according to EN 1092-1 (DIN 2501): PN16

1.4404 (F316/F316L): order code for "Process connection", option D1S Alloy C22: order code for "Process connection", option D1C

Flange with groove according to EN 1092-1 Form D (DIN 2512N): PN16 1.4404 (F316/F316L): order code for "Process connection", option D5S Alloy C22: order code for "Process connection", option D5C

DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]				
100	220	180	8ר18	20	107.1	1 127/1 400 ¹⁾				
150	285	240	8 × Ø22	22	159.3	1 330/1 700 ¹⁾				
250	405	355	12 × Ø26	26	260.4	1775				
Surface roug	Surface roughness (flange): FN 1092-1 Form B1 (DIN 2526 Form C), Ba 3.2 to 12.5 um									

Surface roughness (flange): EN 1092-1 Form B1 (DIN 2526 Form C), Ra 3.2 to 12.5 μm

Installation length in accordance with NAMUR recommendation NE 132 optionally available (order code 1) for "Process connection", option D1N or D5N (with groove))

5	1.4404 (F316/F316L											
DN [mm]	reduction to DN [mm]	Order code for "Process connection", option	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]				
100	80	DHS	220	180	8 × Ø 18	20	107.1	874				
150	100	DJS	285	240	8 × Ø 22	22	159.3	1167				
200 150 DLS 340 295 12 × Ø 22 24 206.5 1461												
Surface roughness (flange): EN 1092-1 Form B1 (DIN 2526 Form C), Ra 3.2 to 12.5 µm												

Flance according to EN 1092-1 (DIN 2501): PN16 with reduction in nominal diamete

Flange according to EN 1092-1 (DIN 2501): PN 40

1.4404 (F316/F316L): order code for "Process connection", option D2S Alloy C22: order code for "Process connection", option D2C

Flange with groove according to EN 1092-1 Form D (DIN 2512N): PN 40 1.4404 (F316/F316L): order code for "Process connection", option D6S Alloy C22: order code for "Process connection", option D6C

-	-									
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]				
8 ¹⁾	95	65	4ר14	16	17.3	370/510 ²⁾				
15	95	65	4 × Ø14	16	17.3	404/510 ²⁾				
25	115	85	4 × Ø14	18	28.5	440/600 ²⁾				
40	150	110	4 × Ø18	18	43.1	550				
50	165	125	4 × Ø18	20	54.5	715/715 ²⁾				
80	200	160	8 × Ø18	24	82.5	840/915 ²⁾				
100	235	190	8 × Ø22	24	107.1	1 1 2 7				
150	300	250	8 × Ø26	28	159.3	1370				
250	450	385	12 × Ø33	38	258.8	1845				
Surface rough	Surface roughness (flange): EN 1092-1 Form B1 (DIN 2526 Form C), Ra 3.2 to 12.5 μm									

1) DN 8 with DN 15 flanges as standard

2) Installation length in accordance with NAMUR recommendation NE 132 optionally available (order code for "Process connection", option D2N or D6N (with groove))

Flange according to EN 1092-1 (DIN 2501): PN 40 (with DN 25 flanges) 1.4404 (F316/F316L): order code for "Process connection", option R2S DN С Α В D Ε L [mm] [mm] [mm] [mm] [mm] [mm] [mm] 8 115 85 $4 \times Ø14$ 18 28.5 440 15 115 85 $4 \times Ø14$ 18 28.5 440

Surface roughness (flange): EN 1092-1 Form B1 (DIN 2526 Form C), Ra 3.2 to 12.5 μm

Flange according to EN 1092-1 (DIN 2501): PN 40 with reduction in nominal diameter 1.4404 (F316/F316L)

	· · · · · · · · · · · ,									
DN [mm]	reduction to DN [mm]	Order code for "Process connection", option	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]		
50	40	DFS	165	125	4ר18	20	54.5	555		
80	50	DGS	200	160	8ר18	24	82.5	840		
100	80	DIS	235	190	8 × Ø 22	24	107.1	874		
150	100	DKS	300	250	8 × Ø 26	28	159.3	1167		
200	150	DMS	375	320	12 × Ø 30	34	206.5	1461		
Surface ro	Surface roughness (flange): EN 1092-1 Form B1 (DIN 2526 Form C), Ra 3.2 to 12.5 µm									

Flange according to EN 1092-1 (DIN 2501): PN 63

1.4404 (F316/F316L): order code for "Process connection", option D3S Alloy C22: order code for "Process connection", option D3C

Flange with groove according to EN 1092-1 Form D (DIN 2512N): PN 63 1.4404 (F316/F316L): order code for "Process connection", option D7S Alloy C22: order code for "Process connection", option D7C

DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]
50	180	135	4 × Ø22	26	54.5	724
80	215	170	8 × Ø22	28	81.7	875
100	250	200	8 × Ø26	30	106.3	1127
150	345	280	8 × Ø33	36	157.1	1410
250	470	400	12 × Ø36	46	255.4	1885

Surface roughness (flange):

EN 1092-1 Form B1 (DIN 2526 Form C), Ra 3.2 to 12.5 μm EN 1092-1 Form B2 (DIN 2526 Form E), Ra 0.8 to 3.2 μm

Flange according to EN 1092-1 (DIN 2501): PN 100

1.4404 (F316/F316L): order code for "Process connection", option D4S Alloy C22: order code for "Process connection", option D4C

Flange with groove according to EN 1092-1 Form D (DIN 2512N): PN 100 1.4404 (F316/F316L): order code for "Process connection", option D8S Alloy C22: order code for "Process connection", option D8C

DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]
8 ¹⁾	105	75	4 × Ø14	20	17.3	400
15	105	75	4 × Ø14	20	17.3	420
25	140	100	4 × Ø18	24	28.5	470
40	170	125	4 × Ø22	26	42.5	590
50	195	145	4 × Ø26	28	53.9	740
80	230	180	8 × Ø26	32	80.9	885
100	265	210	8 × Ø30	36	104.3	1127
150	355	290	12 × Ø33	44	154.0	1450
a ()	((1))))))				·	1

Surface roughness (flange): EN 1092-1 Form B2 (DIN 2526 Form E), Ra 0.8 to 3.2 μm

1) DN 8 with DN 15 flanges as standard

Flange according to EN 1092-1 (DIN 2501): PN 100 Alloy C22: order code for "Process connection", option D4C								
Flange with groove according to EN 1092-1 Form D (DIN 2512N): PN 100 Alloy C22: order code for "Process connection", option D8C								
DN [mm]								
250	505	430	12 × Ø39	60	248.0	1949		
Surface roughr	Surface roughness (flange): EN 1092-1 Form B2 (DIN 2526 Form E), Ra 0.8 to 3.2 µm							

Alloy C22: order code for "Process connection", option AAC									
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mn			
8 ¹⁾	90	60.3	4 × Ø15.7	11.2	15.7	370			
15	90	60.3	4 × Ø15.7	11.2	15.7	40			
25	110	79.4	4 × Ø15.7	14.2	26.7	44			
40	125	98.4	4 × Ø15.7	17.5	40.9	550			
50	150	120.7	4ר19.1	19.1	52.6	71			
80	190	152.4	4ר19.1	23.9	78.0	840			
100	230	190.5	8ר19.1	23.9	102.4	112			
150	280	241.3	8 × Ø22.4	25.4	154.2	139			
250	405	362	12 × Ø25.4	30.2	254.5	183			

Surface roughness (flange): Ra 3.2 to 6.3 μ m

1) DN 8 with DN 15 flanges as standard

Flange according to ASME B16.5: Class 150 with reduction in nominal diameter 1.4404 (F316/F316L)

DN [mm]	reduction to DN [mm]	Order code for "Process connection", option	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]			
50	40	AHS	150	120.7	4 × Ø 19.1	19.1	52.6	550			
80	50	AJS	190	152.4	4 × Ø 19.1	23.9	78.0	720			
100	80	ALS	230	190.5	8 × Ø 19.1	23.9	102.4	874			
150	100	ANS	280	241.3	8 × Ø 22.4	25.4	154.2	1167			
200	150	APS	345	298.5	8 × Ø 22.4	29	202.7	1461			
Surface ro	Surface roughness (flange): Ra 3.2 to 6.3 µm										

Flange according to ASME B16.5: Class 300

1.4404 (F316/F316L): order code for "Process connection", option ABS

Alloy C22: order code for "Process connection", option ABC

,	, Fr								
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]			
8 ¹⁾	95	66.7	4 × Ø15.7	14.2	15.7	370			
15	95	66.7	4 × Ø15.7	14.2	15.7	404			
25	125	88.9	4 × Ø19.1	17.5	26.7	440			
40	155	114.3	4 × Ø22.3	20.6	40.9	550			
50	165	127	8 × Ø19.1	22.3	52.6	715			
80	210	168.3	8 × Ø22.3	28.4	78.0	840			
100	255	200	8 × Ø22.3	31.7	102.4	1127			
150	320	269.9	12 × Ø22.3	36.5	154.2	1417			
250	445	387.4	16 × Ø28.4	47.4	254.5	1863			
Surface rough	Surface roughness (flange): Ra 3.2 to 6.3 µm								

1) DN 8 with DN 15 flanges as standard

5	Flange according to ASME B16.5: Class 300 with reduction in nominal diameter 1.4404 (F316/F316L)									
DN [mm]	reduction to DN [mm]	Order code for "Process connection", option	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]		
50	40	AIS	165	127	8 × Ø 19.1	22.3	52.6	615		
80	50	AKS	210	168.3	8 × Ø 22.3	28.4	78.0	732		
100	80	AMS	255	200	8 × Ø 22.3	31.7	102.4	894		
150	100	AOS	320	269.9	12 × Ø 22.3	36.5	154.2	1187		
200	150	AQS	380	330.2	12 × Ø 25.4	41.7	202.7	1461		
Surface ro	Surface roughness (flange): Ra 3.2 to 6.3 µm									

Flange according to ASME B16.5: Class 600 1.4404 (F316/F316L): order code for "Process connection", option ACS

Alloy C22: order code for "Process conne	ection", option
--	-----------------

DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]
8 ¹⁾	95	66.7	4 × Ø15.7	20.6	13.9	400
15	95	66.7	4 × Ø15.7	20.6	13.9	420
25	125	88.9	4 × Ø19.1	23.9	24.3	490
40	155	114.3	4 × Ø22.3	28.7	38.1	600
50	165	127	8ר19.1	31.8	49.2	742
80	210	168.3	8ר22.3	38.2	73.7	900
100	275	215.9	8ר25.4	48.4	97.3	1157
150	355	292.1	12 × Ø28.4	47.8	154.2	1467
250	510	431.8	16 × Ø35.1	69.9	254.5	1946
Surface rough	ness (flange): F	Ra 3.2 to 6.3 μn	1			

DN 8 with DN 15 flanges as standard 1)

1.4404 (F316	Flange JIS B2220: 10K 1.4404 (F316/F316L): order code for "Process connection", option NDS Alloy C22: order code for "Process connection", option NDC									
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]				
50	155	120	4 × Ø19	16	50	715				
80	185	150	8 × Ø19	18	80	832				
100	210	175	8 × Ø19	18	100	1127				
150	280	240	8 × Ø23	22	150	1354				
250	400	355	12 × Ø25	24	250	1775				
Surface rough	ness (flange): Ra	a 3.2 to 6.3 µm								

Flange JIS B2220: 20K

1.4404 (F316/F316L): order code for "Process connection", option NES Alloy C22: order code for "Process connection", option NEC

Alloy CZZ. 010	Anoy C22. order code for Process connection, option NEC									
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]				
8 ¹⁾	95	70	4 × Ø15	14	15	370				
15	95	70	4 × Ø15	14	15	404				
25	125	90	4 × Ø19	16	25	440				
40	140	105	4 × Ø19	18	40	550				
50	155	120	8 × Ø19	18	50	715				
80	200	160	8 × Ø23	22	80	832				
100	225	185	8 × Ø23	24	100	1127				
150	305	260	12 × Ø25	28	150	1386				
250	430	380	12 × Ø27	34	250	1845				
Surface rough	Surface roughness (flange): Ra 1.6 to 3.2 μm									

1) DN 8 with DN 15 flanges as standard

Flange JIS B2220: 40K

1.4404 (F316/F316L): order code for "Process connection", option NGS Alloy C22: order code for "Process connection", option NGC

	,	· · ·								
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]				
8 ¹⁾	115	80	4 × Ø19	20	15	400				
15	115	80	4 × Ø19	20	15	425				
25	130	95	4 × Ø19	22	25	485				
40	160	120	4 × Ø23	24	38	600				
50	165	130	8 × Ø19	26	50	760				
80	210	170	8 × Ø23	32	75	890				
100	250	205	8 × Ø25	36	100	1167				
150	355	295	12 × Ø33	44	150	1498				
C f										

Surface roughness (flange): Ra 1.6 to 3.2 μ m


1) DN 8 with DN 15 flanges as standard

Flange JIS B2220: 63K 1.4404 (F316/F316L): order code for "Process connection", option NHS Alloy C22: order code for "Process connection", option NHC DN в С D Е Α L [mm] [mm] [mm] [mm] [mm] [mm] [mm] 8 ¹⁾ 120 85 $4 \times Ø19$ 23 12 420 15 120 85 4ר19 23 12 440 25 140 100 4 × Ø23 27 22 494 40 175 130 4ר25 32 35 620 8 × Ø23 775 50 185 145 34 48 80 230 185 8 × Ø25 40 73 915 100 270 220 8ר27 98 44 1167

Flange JIS B2220: 63K 1.4404 (F316/F316L): order code for "Process connection", option NHS Alloy C22: order code for "Process connection", option NHC										
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]				
150	365	305	12 × Ø33	54	146	1528				
Surface roughness (flange): Ra 1.6 to 3.2 µm										

1) DN 8 with DN 15 flanges as standard

Fixed flange DIN 11864-2



Detail X: Asymmetrical process connection; the part shown in blue is provided by the supplier. 🛃 37

Length tolerance for dimension L in mm: +1.5 / -2.0


Flange DIN11864-2 Form A, for pipe according to DIN11866 series A, flat with notch
1.4404 (316/316L)
Order code for "Process connection" option KCS

· · · · · · · · · · · · · · · · · · ·		· / · [· · · · · · · · · ·				
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	L [mm]
8	54	37	4 × Ø9	10	10	387
15	59	42	4 × Ø9	10	16	418
25	70	53	4 × Ø9	10	26	454
40	82	65	4 × Ø9	10	38	560
50	94	77	4 × Ø9	10	50	720
80	133	112	8ר11	12	81	900
100	159	137	8ר11	14	100	1127

3A-version available: order code for "Additional approval", option LP in conjunction with

 $Ra \le 0.8 \ \mu\text{m}$: order code for "Measuring tube material", option SB, SE or $Ra \le 0.4 \ \mu\text{m}$: order code for "Measuring tube material", option SC, SF

Lap joint flange EN 1092-1, ASME B16.5, JIS B2220





Length tolerance for dimension L in mm: +1.5 / -2.0

1.4301 (F	304), wetted	l parts Alloy	1092-1 Form D: I C22 option DAC	PN 40				
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	F [mm]	L [mm]	L _{diff} ¹⁾ [mm]
8 ²⁾	95	65	$4 \times \emptyset$ 14	14.5	45	17.3	370	0
15	95	65	4ר14	14.5	45	17.3	404	0
25	115	85	4ר14	16.5	68	28.5	444	+4
40	150	110	4 × Ø 18	21	88	43.1	560	+10
50	165	125	4 × Ø 18	23	102	54.5	719	+4
80	200	160	8 × Ø 18	29	138	82.5	848	+8
100	235	190	8 × Ø 22	34	162	107.1	1131	+4
Surface rou	1ghness (fla:	nge): Ra 3.2	to 12.5 µm		1			

1) Difference to installation length of the welding neck flange (order code for "Process connection", option D2C)

2) DN 8 with DN 15 flanges as standard

1.4301 (F3	304), wetted	l parts Alloy	ME B16.5: Class 1 C22 , option ADC	.50				
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	F [mm]	L [mm]	L _{diff} ¹⁾ [mm]
8 ²⁾	90	60.3	4 × Ø 15.7	15	35.1	15.7	370	0
15	90	60.3	4 × Ø 15.7	15	35.1	15.7	404	0
25	110	79.4	4 × Ø 15.7	16	50.8	26.7	440	0
40	125	98.4	4 × Ø 15.7	15.9	73.2	40.9	550	0
50	150	120.7	4 × Ø 19.1	19	91.9	52.6	715	0
80	190	152.4	4 × Ø 19.1	22.3	127.0	78.0	840	0

1.4301 (F3	304), wetted	l parts Alloy	ME B16.5: Class 1 C22 . option ADC	150				
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	F [mm]	L [mm]	L _{diff} ¹⁾ [mm]
100	230	190.5	8 × Ø 19.1	26	157.2	102.4	1127	0
Surface rou	ıghness (flai	nge): Ra 3.2	to 12.5 µm					

1) Difference to installation length of the welding neck flange (order code for "Process connection", option AAC)

2) DN 8 with DN 15 flanges as standard

Lap joint flange according to ASME B16.5: Class 300

1.4301 (F304), wetted parts Alloy C22

Order code		connection"	, option AEC					
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	F [mm]	L [mm]	L _{diff} ¹⁾ [mm]
8 ²⁾	95	66.7	4 × Ø 15.7	16.5	35.1	15.7	376	+6
15	95	66.7	4 × Ø 15.7	16.5	35.1	15.7	406	+2
25	125	88.9	4 × Ø 19.1	21.0	50.8	26.7	450	+10
40	155	114.3	4 × Ø 22.3	23.0	73.2	40.9	564	+14
50	165	127	8 × Ø 19.1	25.5	91.9	52.6	717	+2
80	210	168.3	8 × Ø 22.3	31.0	127.0	78.0	852.6	+12.6
100	255	200	8 × Ø 22.3	32.0	157.2	102.4	1139	+12
Surface rou	ighnoss (fla	$(\mathbf{p}_{\alpha}) \cdot \mathbf{P}_{\alpha} \ge 2$	to 12.5 um					

Surface roughness (flange): Ra 3.2 to 12.5 µm

Difference to installation length of the welding neck flange (order code for "Process connection", option 1) ABC)

2) DN 8 with DN 15 flanges as standard

Lap joint flange according to ASME B16.5: Class 600 **1.4301 (F304)**, wetted parts Alloy C22 Order code for "Process connection", option AFC

Order code	Order code for Process connection, option Arc							
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	F [mm]	L [mm]	L _{diff} ¹⁾ [mm]
8 ²⁾	95	66.7	4 × Ø 15.7	17.0	35.1	13.9	400	0
15	95	66.7	4 × Ø 15.7	17.0	35.1	13.9	420	0
25	125	88.9	4 × Ø 19.1	21.5	50.8	24.3	490	0
40	155	114.3	4 × Ø 22.3	25.0	73.2	38.1	600	0
50	165	127	8 × Ø 19.1	28.0	91.9	49.2	742	0
80	210	168.3	8 × Ø 22.3	35.0	127.0	73.7	900	0
100	275	215.9	8 × Ø 25.4	44.0	157.2	97.3	1167	+10
Surface rou	ughness (fla	nge): Ra 3.2	to 12.5 µm					

1) Difference to installation length of the welding neck flange (order code for "Process connection", option ACC)

DN 8 with DN 15 flanges as standard 2)


	for "Process c	, - I	1		1	1		1
DN [mm]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	F [mm]	L [mm]	L _{diff} ¹ [mm]
8 ²⁾	95	70	4 × Ø 15	14	51	15	370	0
15	95	70	4 × Ø 15	14	51	15	404	0
25	125	90	4 × Ø 19	18.5	67	25	440	0
40	140	105	4 × Ø 19	18.5	81	40	550	0
50	155	120	8ר19	23	96	50	715	0
80	200	160	8 × Ø 23	29	132	80	844	+12
100	225	185	8ר23	29	160	100	1127	0

Difference to installation length of the welding neck flange (order code for "Process connection", option 1) NEC) DN 8 with DN 15 flanges as standard

2)

Clamp connections

Tri-Clamp



Length tolerance for dimension L in mm: +1.5 / -2.0

1.4404 (316/316L)	pipe according to DIN 1 s connection", option FD			
DN [mm]	Clamp [in]	A [mm]	B [mm]	L [mm]
8	1/2	25.0	9.5	367
15	1/2	25.0	9.5	398
3-A version available	order code for "Additio	nal approval" option I	P in conjunction with	

3-A version available: order code for "Additional approval", option $\ensuremath{\mathbf{LP}}$ in conjunction with

 $Ra \le 0.8 \ \mu\text{m}$: order code for "Measuring tube material", option SB, SE or

 $Ra \leq 0.4~\mu m$: order code for "Measuring tube material", option SC, SF

Tri-Clamp (\geq 1"), for pipe according to DIN 11866 series C 1.4404 (316/316L)

Order code for "Process connection", option FTS

DN [mm]	Clamp [in]	A [mm]	B [mm]	L [mm]
8	1	50.4	22.1	367
15	1	50.4	22.1	398
25	1	50.4	22.1	434
40	11⁄2	50.4	34.8	560
50	2	63.9	47.5	720
80	3	90.9	72.9	900
100	4	118.9	97.4	1 127


3-A version available: order code for "Additional approval", option LP in conjunction with

 $Ra \leq 0.8~\mu m$: order code for "Measuring tube material", option SB, SE or

 $Ra \leq 0.4~\mu m$: order code for "Measuring tube material", option SC, SF

Threaded couplings

Thread DIN 11851, DIN11864-1, SMS 1145





Length tolerance for dimension L in mm: +1.5 / -2.0

Thread DIN 11851, for p 1.4404 (316/316L) Order code for "Process con	ipe according to DIN11866, serie	es A	
DN [mm]	A [in]	B [mm]	L [mm]
8	Rd 34 × 1/8	16	367
15	Rd 34 × 1/8	16	398
25	Rd 52 × 1/ ₆	26	434
40	Rd 65 × 1/ ₆	38	560
50	Rd 78 × 1/ ₆	50	720
80	Rd 110 × ¼	81	900
100	Rd 130 × ¼	100	1127
3-A version available: ord	er code for "Additional approval"	ntion I.P in conjunction wi	th

3-A version available: order code for "Additional approval", option LP in conjunction with Ra $\leq 0.8~\mu m$: order code for "Measuring tube material", option SB, SE

Order code for "Process connection", option FLW					
DN [mm]	A [in]	B [mm]	L [mm]		
8	Rd 28 × 1/8	10	367		
15	Rd 34 × 1/8	16	398		
25	Rd 52 × ¹ / ₈	26	434		
40	Rd 65 × ¼	38	560		
50	Rd 78 × ¼	50	720		
80	Rd 110 × ¼	81	900		
100	Rd 130 × ¼	100	1127		

3-A version available: order code for "Additional approval", option $\ensuremath{\mathbf{LP}}$ in conjunction with

 $\text{Ra} \leq 0.8~\mu\text{m}$: order code for "Measuring tube material", option SB, SE or


 $Ra \leq 0.4~\mu m$: order code for "Measuring tube material", option SC, SF

Order code for "Process co	nnection", option SCS		
DN [mm]	A [in]	B [mm]	L [mm]
8	Rd 40 × ¹ ⁄ ₆	22.6	367
15	Rd 40 × ¹ ⁄ ₆	22.6	398
25	Rd 40 × ¹ ⁄ ₆	22.6	434
40	Rd 60 × ¹ ⁄ ₆	35.6	560
50	Rd 70 × ¹ / ₆	48.6	720
80	Rd 98 × ¼	72.9	900
100	Rd 132 × 1/ ₆	97.6	1 1 2 7

Ra \leq 0.8 µm: order code for "Measuring tube material", option SB, SE

Thread ISO 2853

f




Length tolerance for dimension L in mm: +1.5 / -2.0

Thread ISO 2853, for pipe according to ISO 2037 1.4404 (316/316L) Order code for "Process connection", option JSF										
DN [mm]	A ¹⁾ [mm]	B [mm]	L [mm]							
8	37.13	22.6	367							
15 37.13 22.6 398										
25	37.13	22.6	434							
40	52.68	35.6	560							
50	64.16	48.6	720							
80	91.19	72.9	900							
100	118.21	97.6	1127							
3-A version available: orde	r code for "Additional approva	l", option LP in conjunction v	vith							

3-A version available: order code for "Additional approval", option LP in conjunction with Ra $\leq 0.8~\mu m$: order code for "Measuring tube material", option SB, SE or Ra $\leq 0.4~\mu m$: order code for "Measuring tube material", option SC, SF

1) Max. thread diameter as per ISO 2853 annex A

VCO




Length tolerance for dimension L in mm: +1.5 / -2.0

8-VCO-4 (½") 1.4404 (316/316L) Order code for "Process conne	ection", option CVS		
DN [mm]	A [in]	B [mm]	L [mm]
8	AF 1	10.2	390

12-VCO-4 (¾") 1.4404 (316/316L) Order code for "Process conr	nection", option CWS		
DN [mm]	A [in]	B [mm]	L [mm]
15	AF 1½	15.7	430

Accessories

Rupture disk/purge connections




🖸 38


- 1 Connection nipple for purge connections: order code for "Sensor options", option CH "Purge connection"
- 2 Connection nipple with rupture disk: order code for "Sensor option", option CA "Rupture disk"

DN	А	L
[mm]	[mm]	[mm]
8	62	216
15	62	220
25	62	260
40	67	310
50	79	452
80	101	560
100	120	684
150	141	880
250	182	380

Protective cover



Remote display and operating module DKX001




🗷 39 Engineering unit mm (in)

External WLAN antenna

 \mathbf{I}

The external WLAN antenna is not suitable for use in hygienic applications.


External WLAN antenna mounted on device



☑ 40 Engineering unit mm (in)

External WLAN antenna mounted with cable


The external WLAN antenna can be mounted separately from the transmitter if the transmission/ reception conditions at the transmitter mounting location are poor.



■ 41 Engineering unit mm (in)

Dimensions in US units

Compact version



Order code for "Housing", option A "Aluminum, coated"

DN	A 1)	B 1)	С	D	E ²⁾³⁾	F ²⁾³⁾	G ⁴⁾	Н	I ⁴⁾	К	L	М
[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
3/8	6.65	2.68	3.98	2.95	10.22	13.17	7.87	2.32	5.55	0.211	5)	2.76
1/2	6.65	2.68	3.98	2.95	10.22	13.17	7.87	2.32	5.55	0.33	5)	2.76
1	6.65	2.68	3.98	2.95	10.22	13.17	7.87	2.32	5.55	0.47	5)	2.76
1½	6.65	2.68	3.98	4.13	10.41	14.55	7.87	2.32	5.55	0.69	5)	3.11
2	6.65	2.68	3.98	5.55	10.81	16.36	7.87	2.32	5.55	1.02	5)	3.90
3	6.65	2.68	3.98	7.87	11.59	19.47	7.87	2.32	5.55	1.59	5)	5.47
4	6.65	2.68	3.98	10.00	12.30	22.30	7.87	2.32	5.55	2.02	5)	6.93
6	6.65	2.68	3.98	14.88	13.13	28.01	7.87	2.32	5.55	2.71	5)	8.58
10	6.65	2.68	3.98	21.57	14.86	36.44	7.87	2.32	5.55	4.03	5)	12.01

1) Depending on the cable gland used: values up to + 1.18 in

With order code for "Sensor option", option CG or order code for "Measuring tube material", option SD, SE, 2) SF, TH, LA: values +2.76 in

3) With order code for "Measuring tube material", option TT, TU: values +4.09 in

4) 5) For version without local display: values - 1.18 in Depends on the process connection in question

Order code	for "Housina".	option A	"Aluminum.	coated"; Ex d

DN	A 1)	B 1)	С	D	E ²⁾³⁾	F	G ⁴⁾	Н	I	К	L	М
[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
3/8	7.40	3.35	4.06	2.95	11.42	14.37	8.54	2.28	5.83	0.211	5)	2.76
1/2	7.40	3.35	4.06	2.95	11.42	14.37	8.54	2.28	5.83	0.33	5)	2.76
1	7.40	3.35	4.06	2.95	11.42	14.37	8.54	2.28	5.83	0.47	5)	2.76
1½	7.40	3.35	4.06	4.13	11.59	15.73	8.54	2.28	5.83	0.69	5)	3.11
2	7.40	3.35	4.06	5.55	11.99	17.54	8.54	2.28	5.83	1.02	5)	3.90
3	7.40	3.35	4.06	7.87	12.78	20.65	8.54	2.28	5.83	1.59	5)	5.47
4	7.40	3.35	4.06	10	13.48	23.48	8.54	2.28	5.83	2.02	5)	6.93

DN	A 1)	B 1)	С	D	E ²⁾³⁾	F	G ⁴⁾	Н	I	К	L	М
[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
6	7.40	3.35	4.06	14.88	14.31	29.19	8.54	2.28	5.83	2.71	5)	8.58
10	7.40	3.35	4.06	21.57	16.04	37.62	8.54	2.28	5.83	4.03	5)	12.01

1) Depending on the cable gland used: values up to + 1.18 in

2) With order code for "Sensor option", option CG or order code for "Measuring tube material", option SD, SE, SF, TH, LA: values +2.76 in

3) With order code for "Measuring tube material", option TT, TU: values +4.09 in

4) For version without local display: values - 1.93 in

5) Depends on the process connection in question

Ordon codo	for "Llouging"	option B "Stainless,	hugionia"
Uldel Code	loi nousina.	ODHORID SIGURESS.	nvalenic

DN	A 1)	B 1)	С	D	E ²⁾³⁾	F	G ⁴⁾	Н	I	К	L	М
[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
3/8	7.20	2.87	4.33	2.95	10.22	13.17	8.15	2.56	5.59	0.211	5)	2.76
1/2	7.20	2.87	4.33	2.95	10.22	13.17	8.15	2.56	5.59	0.33	5)	2.76
1	7.20	2.87	4.33	2.95	10.22	13.17	8.15	2.56	5.59	0.47	5)	2.76
11/2	7.20	2.87	4.33	4.13	10.41	14.55	8.15	2.56	5.59	0.69	5)	3.11
2	7.20	2.87	4.33	5.55	10.81	16.36	8.15	2.56	5.59	1.02	5)	3.90
3	7.20	2.87	4.33	7.87	11.59	19.47	8.15	2.56	5.59	1.59	5)	5.47
4	7.20	2.87	4.33	10.00	12.30	22.30	8.15	2.56	5.59	2.02	5)	6.93
6	7.20	2.87	4.33	14.88	13.13	28.01	8.15	2.56	5.59	2.71	5)	8.58
10	7.20	2.87	4.33	21.57	14.86	36.44	8.15	2.56	5.59	4.03	5)	12.01

1) Depending on the cable gland used: values up to + 1.18 in

2) With order code for "Sensor option", option CG or order code for "Measuring tube material", option SD, SE, SF, TH, LA: values +2.76 in

3) With order code for "Measuring tube material", option TT, TU: values +4.09 in

4) For version without local display: values - 0.51 in

5) Depends on the process connection in question

Order code for "Housing", option L "Cast, stainless"

DN	A 1)	B 1)	C	D	E ²⁾³⁾	F	G	Н	I	К	L	М
[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
3/8	7.32	3.35	3.98	2.95	11.42	14.37	8.7	2.48	6.22	0.211	4)	2.76
1/2	7.32	3.35	3.98	2.95	11.42	14.37	8.7	2.48	6.22	0.33	4)	2.76
1	7.32	3.35	3.98	2.95	11.42	14.37	8.7	2.48	6.22	0.47	4)	2.76
1½	7.32	3.35	3.98	4.13	11.59	15.73	8.7	2.48	6.22	0.69	4)	3.11
2	7.32	3.35	3.98	5.55	11.99	17.54	8.7	2.48	6.22	1.02	4)	3.90
3	7.32	3.35	3.98	7.87	12.78	20.65	8.7	2.48	6.22	1.59	4)	5.47
4	7.32	3.35	3.98	10	13.48	23.48	8.7	2.48	6.22	2.02	4)	6.93
6	7.32	3.35	3.98	14.88	14.31	29.19	8.7	2.48	6.22	2.71	4)	8.58
10	7.32	3.35	3.98	21.57	16.04	37.62	8.7	2.48	6.22	4.03	4)	12.01

1) Depending on the cable gland used: values up to + 1.18 in


2) With order code for "Sensor option", option CG or order code for "Measuring tube material", option SD, SE, SF, TH, LA: values +2.76 in

3) With order code for "Measuring tube material", option TT, TU: values +4.09 in

4) Depends on the process connection in question

Flange connections

Fixed flange ASME B16.5



Length tolerance for dimension L in inch: • $DN \le 4": +0.06 / -0.08$

■ DN ≥ 5": +0.14

Flange according to ASME B16.5: Class 150

1.4404 (F316/F316L): order code for "Process connection", **option AAS Alloy C22**: order code for "Process connection", option **AAC**

DN [in]	A [in]	B [in]	C [in]	D [in]	E [in]	L [in]
3/8 1)	3.54	2.37	4 × Ø 0.62	0.44	0.62	14.57
1/2	3.54	2.37	4 × Ø0.62	0.44	0.62	15.91
1	4.33	3.13	4 × Ø0.62	0.56	1.05	17.32
11/2	4.92	3.87	4 × Ø0.62	0.69	1.61	21.65
2	5.91	4.75	4 × Ø0.75	0.75	2.07	28.15
3	7.48	6.00	4 × Ø0.75	0.94	3.07	33.07
4	9.06	7.50	8 × Ø0.75	0.94	4.03	44.37
6	11.02	9.50	8 × Ø0.88	1	6.07	55.04
10	15.94	14.25	12 × Ø1.0	1.19	10.02	72.13
Surface roug	hness (flange): Ra	a 125 to 250 µin				

1) DN $^3\!\!/_8$ with DN $^1\!\!/_2$ flanges as standard

	ccording to ASI F316/F316L)	ME B16.5: Class 150) with redu	uction in n	iominal diamet	er		
DN [in]	reduction to DN [in]	Order code for "Process connection", option	A [in]	B [in]	C [in]	D [in]	E [in]	L [in]
2	1½	AHS	5.91	4.75	4 × Ø 0.75	0.75	2.07	21.65
3	2	AJS	7.48	6	4 × Ø 0.75	0.94	3.07	28.35
4	3	ALS	9.06	7.5	8 × Ø 0.75	0.94	4.03	34.41
6	4	ANS	11.02	9.5	8 × Ø 0.88	1	6.07	45.94
8	6	APS	13.58	11.75	8 × Ø 0.88	1.14	7.98	57.52
Surface ro	oughness (flang	e): Ra 125 to 250 µii	n					

DN [in]	A [in]	B [in]	C [in]	D [in]	E [in]	L [in]	
3/8 1)	3.74	2.63	4 × Ø0.62	0.56	0.62	14.5	
1/2	3.74	2.63	4 × Ø0.62	0.56	0.62	15.9	
1	4.92	3.50	4 × Ø0.75	0.69	1.05	17.3	
11/2	6.10	4.50	4 × Ø0.88	0.81	1.61	21.6	
2	6.50	5.00	8 × Ø0.75	0.88	2.07	28.1	
3	8.27	6.63	8 × Ø0.88	1.12	3.07	33.0	
4	10.04	7.87	8 × Ø0.88	1.25	4.03	44.3	
6	12.6	10.63	12 × Ø0.88	1.44	6.07	55.7	
10	17.52	15.25	16 × Ø1.12	1.87	10.02	73.3	

1) DN $^3\!\!/_8$ with DN $^1\!\!/_2$ flanges as standard


Flange according to ASME B16.5: Class 300 with reduction in nominal diameter 1.4404 (F316/F316L)

1.1101 (J10/1 J102,							
DN [in]	reduction to DN [in]	Order code for "Process connection", option	A [in]	B [in]	C [in]	D [in]	E [in]	L [in]
2	1½	AIS	6.5	5	8 × Ø 0.75	0.88	2.07	24.21
3	2	AKS	8.27	6.63	8 × Ø 0.88	1.12	3.07	28.82
4	3	AMS	10.04	7.87	8 × Ø 0.88	1.25	4.03	35.2
6	4	AOS	12.6	10.63	12 × Ø 0.88	1.44	6.07	46.73
8	6	AQS	14.96	13	12 × Ø 1	1.64	7.98	57.52
Surface re	oughness (flang	e): Ra 125 to 250 µi	n					

Flange according to ASME B16.5: Class 600 1.4404 (F316/F316L): order code for "Process connection", option ACS

Alloy C22:	order code for "P	rocess connectio	on", option ACC			
DN [in]	A [in]	B [in]	C [in]	D [in]	E [in]	L [in]
3/8 ¹⁾	3.74	2.63	4 × Ø0.62	0.81	0.55	15.75
1/2	3.74	2.63	4 × Ø0.62	0.81	0.55	16.54
1	4.92	3.50	4 × Ø0.75	0.94	0.96	19.29
11/2	6.10	4.50	4 × Ø0.88	1.13	1.5	23.62
2	6.50	5.00	8 × Ø0.75	1.25	1.94	29.21
3	8.27	6.63	8 × Ø0.88	1.5	2.9	35.43
4	10.83	8.50	8ר1.00	1.91	3.83	45.55
6	13.98	11.50	12 × Ø1.12	1.88	6.07	57.76
10	20.08	17.00	16 × Ø1.38	2.75	10.02	76.61
Surface rou	ghness (flange):	Ra 125 to 250	µin			

1) DN $^3\!\!/_8$ with DN $^1\!\!/_2$ flanges as standard Lap joint flange ASME B16.5



Length tolerance for dimension L in inch: +0.06 / -0.08

Order code for "Process connection", option ADC									
DN [in]	A [in]	B [in]	C [in]	D [in]	E [in]	F [in]	L [in]	L _{diff} ¹⁾ [in]	
³ /8 ²⁾	3.54	2.37	4 × Ø 0.62	0.59	1.38	0.62	14.57	0	
1/2	3.54	2.37	4 × Ø 0.62	0.59	1.38	0.62	15.91	0	
1	4.33	3.13	4 × Ø 0.62	0.63	2	1.05	17.32	0	
11/2	4.92	3.87	4 × Ø 0.62	0.63	2.88	1.61	21.65	0	
2	5.91	4.75	4 × Ø 0.75	0.75	3.62	2.07	28.15	0	
3	7.48	6.00	4 × Ø 0.75	0.88	5	3.07	33.07	0	
4	9.06	7.50	8 × Ø 0.75	1.02	6.19	4.03	44.37	0	

1) Difference to installation length of the welding neck flange (order code for "Process connection", option AAC)

2) DN $\frac{3}{8}$ " with DN $\frac{1}{2}$ " flanges as standard

1.4301 (F	Lap joint flange according to ASME B16.5: Class 300 1.4301 (F304), wetted parts Alloy C22 Order code for "Process connection", option AEC										
DN [in]	A [in]	B [in]	C [in]	D [in]	E [in]	F [in]	L [in]	L _{diff} ¹⁾ [in]			
³ /8 ²⁾	3.74	2.63	4 × Ø 0.62	0.65	1.38	0.62	14.8	+0.23			
1/2	3.74	2.63	4 × Ø 0.62	0.65	1.38	0.62	15.98	+0.07			
1	4.92	3.50	4 × Ø 0.75	0.83	2	1.05	17.72	+0.40			
1½	6.10	4.50	4 × Ø 0.88	0.91	2.88	1.61	22.2	+0.55			
2	6.50	5.00	8 × Ø 0.75	1	3.62	2.07	28.23	+0.08			
3	8.27	6.63	8 × Ø 0.88	1.22	5	3.07	33.57	+0.50			

1.4301 (F3	304), wetted	l parts Alloy	ME B16.5: Class 3 C22 , option AEC	800				
DN [in]	A [in]	B [in]	C [in]	D [in]	E [in]	F [in]	L [in]	L _{diff} 1) [in]
4 10.04 7.87 8ר0.88 1.26 6.19 4.03 44.84 +0.47								
Surface rou	Gurface roughness (flange): Ra 125 to 492 μin							

1) Difference to installation length of the welding neck flange (order code for "Process connection", option AAC)

2) DN $\frac{3}{8}$ " with DN $\frac{1}{2}$ " flanges as standard


DN [im]	A	B	C	D	E	F	L	L _{diff} ¹⁾
[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
³ /8 ²⁾	3.74	2.63	4 × Ø 0.62	0.67	1.38	0.55	15.75	0
1/2	3.74	2.63	4 × Ø 0.62	0.67	1.38	0.55	16.54	0
1	4.92	3.50	4 × Ø 0.75	0.85	2	0.96	19.29	0
1½	6.10	4.50	4 × Ø 0.88	0.98	2.88	1.5	23.62	0
2	6.50	5.00	8 × Ø 0.75	1.1	3.62	1.94	29.21	0
3	8.27	6.63	8 × Ø 0.88	1.38	5	2.9	35.43	0
4	10.83	8.50	8ר1	1.73	6.19	3.83	45.94	+0.39


1) Difference to installation length of the welding neck flange (order code for "Process connection", option AAC)

2) DN $\frac{3}{8}$ " with DN $\frac{1}{2}$ " flanges as standard

Clamp connections

Tri-Clamp





1.4404 (316/316L)	Tri-Clamp (½"), DIN 11866 series C 1.4404 (316/316L) Order code for "Process connection", option FDW								
DN [in]	Clamp [in]	A [in]	B [in]	L [in]					
3/8	1/2	0.98	0.37	14.4					
1/2	1/2	0.98	0.37	15.7					

 $3\mathchar`-A$ version available: order code for "Additional approval", option \mbox{LP} in conjunction with

 $Ra \le 32 \mu in:$ order code for "Measuring tube material", option SB, SE or $Ra \le 16 \mu in:$ order code for "Measuring tube material", option SC, SF

Order code for "Process connection", option FTS									
DN [in]	Clamp [in]	A [in]	B [in]	L [in]					
3/8	1	1.98	0.87	14.4					
1/2	1	1.98	0.87	15.7					
1	1	1.98	0.87	17.1					
11/2	1½	1.98	1.37	22.0					
2	2	2.52	1.87	28.3					
3	3	3.58	2.87	35.4					
4	4	4.68	3.83	44.4					


3-A version available: order code for "Additional approval", option LP in conjunction with

Ra \leq 32 µin: order code for "Measuring tube material", option **SB**, **SE** or

 $Ra \le 16 \mu in$: order code for "Measuring tube material", option SC, SF

Threaded couplings

Thread SMS 1145







Length tolerance for dimension L in inch: +0.06 / -0.08

Fhread SMS 1145 1.4404 (316/316L) Order code for "Process co	onnection", option SCS		
DN [in]	A [in]	B [in]	L [in]
3⁄8	Rd 40 × ¼	0.89	14.45
1/2	Rd 40 × ¼	0.89	15.67
1	Rd 40 × ¼	0.89	17.09
11/2	Rd 60 × ¼	1.4	22.05
2	Rd 70 × ¹ / ₆	1.91	28.35
3	Rd 98 × ¼	2.87	35.43
4	Rd 132 × 1/6	3.84	44.37

 $Ra \le 32 \ \mu in:$ order code for "Measuring tube material", option **SB**, **SE**

VCO





8-VCO-4 (½") 1.4404 (316/316L) Order code for "Process con	nection", option CVS		
DN [in]	A [in]	B [in]	L [in]
3⁄8	AF 1	0.4	15.35


12-VCO-4	(¾")

1.4404 (316/316L) Order code for "Process connection", option CWS

DN	A	B	L
[in]	[in]	[in]	[in]
1/2	AF 1½	0.62	

Accessories


Rupture disk/purge connections




Connection nipple for purge connections: order code for "Sensor options", option CH "Purge connection" Connection nipple with rupture disk: order code for "Sensor option", option CA "Rupture disk" 1 2

DN	A	L
[in]	[in]	[in]
3/8	2.44	8.50
1/2	2.44	8.66
1	2.44	10.24
1½	2.64	12.20
2	3.11	17.78
3	3.98	22.0
4	4.72	27.0
6	5.55	34.6
10	7.17	14.96

Protective cover



Remote display and operating module DKX001




■ 42 Engineering unit mm (in)

External WLAN antenna



The external WLAN antenna is not suitable for use in hygienic applications.


External WLAN antenna mounted on device



☑ 43 Engineering unit mm (in)

External WLAN antenna mounted with cable

The external WLAN antenna can be mounted separately from the transmitter if the transmission/ reception conditions at the transmitter mounting location are poor.



☑ 44 Engineering unit mm (in)

Weight

All values (weight exclusive of packaging material) refer to devices with EN/DIN PN 40 flanges. Weight specifications including transmitter as per order code for "Housing", option A "Aluminum, coated".

Different values due to different transmitter versions:

- Transmitter version for the hazardous area
- (Order code for "Housing", option A "Aluminum, coated"; Ex d): +2 kg (+4.4 lbs) Cast transmitter version, stainless
 - (Order code for "Housing", option L "Cast, stainless"): +6 kg (+13 lbs)
- Transmitter version for hygienic area
 - (Order code for "Housing", option B "Stainless, hygienic"): +0.2 kg (+0.44 lbs)

Weight in SI units

DN [mm]	Weight [kg]
8	11
15	12
25	14
40	19
50	30

DN [mm]	Weight [kg]
80	55
100	96
150	154
250	400

Weight in US units

DN [in]	Weight [lbs]
3/8	24
4/2	26
1	31
11/2	42
2	66
3	121
4	212
6	340
10	882

Materials

Transmitter housing

Order code for "Housing":

- Option A "Aluminum, coated": aluminum, AlSi10Mg, coated
- Option **B** "Stainless, hygienic": stainless steel, 1.4404 (316L)
- Option L "Cast, stainless": cast, stainless steel, 1.4409 (CF3M) similar to 316L

Window material


Order code for "Housing":

- Option **A** "Aluminum, coated": glass
- Option B "Stainless, hygienic": polycarbonate
 Option L "Cast, stainless": glass

Seals

Order code for "Housing": Option **B** "Stainless, hygienic": EPDM and silicone

Cable entries/cable glands



■ 45 Possible cable entries/cable glands

- 1 Female thread M20 × 1.5
- 2 Cable gland M20 × 1.5
- 3 Adapter for cable entry with internal thread G $\frac{1}{2}$ or NPT $\frac{1}{2}$
- 4 Device plugs

Order code for "Housing", option A "Aluminum, coated"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material
Cable gland M20 × 1.5	Plastic/nickel-plated brass
Adapter for cable entry with internal thread G $\frac{1}{2}$	Nickel-plated brass
Adapter for cable entry with internal thread NPT ½"	

Order code for "Housing", option B "Stainless, hygienic"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material
Cable gland M20 × 1.5	Plastic
Adapter for cable entry with internal thread G ¹ /2"	Nickel-plated brass
Adapter for cable entry with internal thread NPT ½"	

Order code for "Housing", option L "Cast, stainless"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material
Cable gland M20 × 1.5	Stainless steel, 1.4404 (316L)
Adapter for cable entry with internal thread G $\frac{1}{2}$ "	
Adapter for cable entry with internal thread NPT $\frac{1}{2}$ "	

Device plug

Electrical connection	Material
Plug M12x1	Socket: Stainless steel, 1.4404 (316L)Contact housing: PolyamideContacts: Gold-plated brass

Sensor housing

The material of the sensor housing depends on the option selected in the order code for "Measuring tube mat., wetted surface".

Order code for "Measuring tube mat., wetted surface"	Material
Option HA, SA, SD, TH	Acid and alkali-resistant outer surfaceStainless steel 1.4301 (304)
	With order code for "Sensor option", option CC "316L Sensor housing": stainless steel, 1.4404 (316L)
Option SB, SC, SE, SF	Acid and alkali-resistant outer surfaceStainless steel 1.4301 (304)
Option TT , TU , LA	Acid and alkali-resistant outer surfaceStainless steel, 1.4404 (316L)

Measuring tubes

- DN 8 to 100 (3/8...4"): stainless steel, 1.4539 (904L); Manifold: stainless steel, 1.4404 (316/316L)
- DN 150 (6"), DN 250 (10"): stainless steel, 1.4404 (316/316L); Manifold: stainless steel, 1.4404 (316/316L)
- DN 8 to 250 (3/8 to 10"): Alloy C22, 2.4602 (UNS N06022); Manifold: Alloy C22, 2.4602 (UNS N06022)

High-temperature version DN 25, DN 50, DN 80 (DN 1", DN 2", DN 3"): Alloy C22, 2.4602 (UNS N06022)

Process connections

- Flanges according to EN 1092-1 (DIN2501) / according to ASME B 16.5 / as per JIS B2220:
 - Stainless steel, 1.4404 (F316/F316L)
 - Alloy C22, 2.4602 (UNS N06022)
 - Lap joint flanges: stainless steel, 1.4301 (F304); wetted parts Alloy C22
- All other process connections:

Stainless steel, 1.4404 (316/316L)

High-temperature version

Flanges according to EN 1092-1 (DIN2501) / according to ASME B 16.5 / as per JIS B2220:

- Stainless steel, 1.4404 (F316/F316L)
- Alloy C22, 2.4602 (UNS N06022)

Available process connections→ 🗎 99

Seals

Welded process connections without internal seals

Accessories

Protective cover

Stainless steel, 1.4404 (316L)

External WLAN antenna

- Antenna: ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel-plated brass
- Adapter: Stainless steel and nickel-plated brass
- Cable: Polyethylene
- Plug: Nickel-plated brass
- Angle bracket: Stainless steel

Process connections	 Fixed flange connections: EN 1092-1 (DIN 2501) flange EN 1002-1 (DIN 2512) flange 			
	– EN 1092-1 (DIN 2512N) flange – Namur lengths in accordance with NE 132			
	 ASME B16.5 flange JIS B2220 flange DIN 11864-2 Form A flange, DIN 11866 series A, flange with notch 			
				 Clamp connections:
	Tri-Clamp (OD tubes), DIN 11866 series C			
		 Thread: DIN 11851 thread, DIN 11866 series A SMS 1145 thread ISO 2853 thread, ISO 2037 DIN 11864-1 Form A thread, DIN 11866 series A 		
	 VCO connections: - 8-VCO-4 - 12-VCO-4 			
	Process connection materials $\rightarrow \triangleq 98$			
Surface roughness	All data relate to parts in contact with fluid. The following surface roughness quality can be ordered • Not polished			

- $Ra_{max} = 0.8 \ \mu m (32 \ \mu in)$ $Ra_{max} = 0.4 \ \mu m (16 \ \mu in)$

Operability


Operating concept	Operator-oriented menu structure for user-specific tasks Commissioning Operation Diagnostics Expert level 		
	 Fast and safe commissioning Guided menus ("Make-it-run" wizards) for applications Menu guidance with brief descriptions of the individual parameter functions Device access via Web server or SmartBlue app → 119 WLAN access to the device via mobile handheld terminal, tablet or smart phone 		
	 Reliable operation Operation in local language → ● 99 Uniform operating philosophy applied to device and operating tools If replacing electronic modules, transfer the device configuration via the integrated memory (HistoROM backup) which contains the process and measuring device data and the event logbook. No need to reconfigure. 		
	 Efficient diagnostics increase measurement availability Troubleshooting measures can be called up via the device and in the operating tools Diverse simulation options, logbook for events that occur and optional line recorder functions 		
Languages	 Can be operated in the following languages: Via local operation English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Korean, Bahasa (Indonesian), Vietnamese, Czech, Swedish Via Web browser English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Korean, Bahasa (Indonesian), Vietnamese, Czech, Swedish Via "FieldCare", "DeviceCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese 		

Local operation

Via display module

- Two display modules are available:
- Order code for "Display; operation", option F "4-line, illuminated, graphic display; touch control"
 Order code for "Display operation", option F "4-line, illuminated, graphic display touch control
- Order code for "Display; operation", option G "4-line, illuminated, graphic display; touch control + WLAN"

Information about WLAN interface $\rightarrow \cong 106$



46 Operation with touch control

Display elements

- 4-line, illuminated, graphic display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display: -20 to +60 °C (-4 to +140 °F)
 The readability of the display may be impaired at temperatures outside the temperature range.


Operating elements

- External operation via touch control (3 optical keys) without opening the housing: ±, ⊡, ₪
- Operating elements also accessible in the various zones of the hazardous area

Via remote display and operating module DKX001

The remote display and operating module DKX001 is available as an optional extra $\rightarrow \square$ 117.

- The remote display and operating module DKX001 is only available for the following housing versions, order code for "Housing":
 - Option A "Aluminum, coated"
 - Option L "Cast, stainless"
- The measuring device is always supplied with a dummy cover when the remote display and operating module DKX001 is ordered directly with the measuring device. Display or operation at the transmitter is not possible in this case.
- If ordered subsequently, the remote display and operating module DKX001 may not be connected at the same time as the existing measuring device display module. Only one display or operation unit may be connected to the transmitter at any one time.



■ 47 Operation via remote display and operating module DKX001

Display and operating elements

The display and operating elements correspond to those of the display module $\rightarrow \square$ 100.

Material

The housing material of the display and operating module DKX001 depends on the choice of transmitter housing material.

Transmitter housing	Remote display and operating module	
Order code for "Housing"	Material	Material
Option A "Aluminum, coated"	AlSi10Mg, coated	AlSi10Mg, coated
Option L "Cast, stainless"	Cast stainless steel, 1.4409 (CF3M) similar to 316L	1.4409 (CF3M)

Cable entry

Corresponds to the choice of transmitter housing, order code for "Electrical connection".

Connecting cable


→ 🗎 43

Dimensions $\rightarrow \blacksquare 83$

Remote operation


Via HART protocol

This communication interface is available in device versions with a HART output.



48 Options for remote operation via HART protocol (active)

- 1 Control system (e.g. PLC)
- 2 Field Communicator 475
- 3 Computer with Web browser (e.g. Internet Explorer) for access to the integrated device Web server or computer with an operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 4 Commubox FXA195 (USB)
- 5 Field Xpert SFX350 or SFX370
- 6 Field Xpert SMT70
- 7 VIATOR Bluetooth modem with connecting cable
- 8 Transmitter




49 Options for remote operation via HART protocol (passive)

- 1 Control system (e.g. PLC)
- 2 Transmitter power supply unit, e.g. RN221N (with communication resistor)
- 3 Connection for Commubox FXA195 and Field Communicator 475
- 4 Field Communicator 475
- 5 Computer with Web browser (e.g. Internet Explorer) for access to the integrated device Web server or computer with an operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 6 Commubox FXA195 (USB)
- 7 Field Xpert SFX350 or SFX370
- 8 Field Xpert SMT70
- 9 VIATOR Bluetooth modem with connecting cable
- 10 Transmitter

Via FOUNDATION Fieldbus network

This communication interface is available in device versions with FOUNDATION Fieldbus.




☑ 50 Options for remote operation via FOUNDATION Fieldbus network

- 1 Automation system
- 2 Computer with FOUNDATION Fieldbus network card
- 3 Industry network
- 4 High Speed Ethernet FF-HSE network
- 5 Segment coupler FF-HSE/FF-H1
- 6 FOUNDATION Fieldbus FF-H1 network
- 7 Power supply FF-H1 network
- 8 T-box
- 9 Measuring device

Via PROFIBUS DP network


This communication interface is available in device versions with PROFIBUS DP.



- ☑ 51 Options for remote operation via PROFIBUS DP network
- 1 Automation system
- 2 Computer with PROFIBUS network card
- 3 PROFIBUS DP network
- 4 Measuring device

Via PROFIBUS PA network

This communication interface is available in device versions with PROFIBUS PA.




■ 52 Options for remote operation via PROFIBUS PA network

- 1 Automation system
- 2 Computer with PROFIBUS network card
- 3 PROFIBUS DP network
- 4 Segment coupler PROFIBUS DP/PA
- 5 PROFIBUS PA network
- 6 T-box
- 7 Measuring device

Via Modbus RS485 protocol

This communication interface is available in device versions with a Modbus-RS485 output.




☑ 53 Options for remote operation via Modbus-RS485 protocol (active)

- 1 Control system (e.g. PLC)
- 2 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or with
- operating tool (e.g. FieldCare, DeviceCare) with COM DTM "CDI Communication TCP/IP" or Modbus DTM
- 3 Transmitter

Via EtherNet/IP network

This communication interface is available in device versions with EtherNet/IP.

Star topology




54 Options for remote operation via EtherNet/IP network: star topology

1 Automation system, e.g. "RSLogix" (Rockwell Automation)

- 2 Workstation for measuring device operation: with Custom Add-On Profile for "RSLogix 5000" (Rockwell Automation) or with Electronic Data Sheet (EDS)
- 3 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or computer with operating tool (e.g. FieldCare, DeviceCare) with COM DTM "CDI Communication TCP/IP"
- 4 Ethernet switch
- 5 Measuring device

Ring topology

The device is integrated via the terminal connection for signal transmission (output 1) and the service interface (CDI-RJ45).




☑ 55 Options for remote operation via EtherNet/IP network: ring topology

- 1 Automation system, e.g. "RSLogix" (Rockwell Automation)
- 2 Workstation for measuring device operation: with Custom Add-On Profile for "RSLogix 5000" (Rockwell Automation) or with Electronic Data Sheet (EDS)
- 3 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or computer with operating tool (e.g. FieldCare, DeviceCare) with COM DTM "CDI Communication TCP/IP"
- 4 Ethernet switch
- 5 Measuring device

Via PROFINET network

This communication interface is available in device versions with PROFINET.

Star topology




☑ 56 Options for remote operation via PROFINET network: star topology

- 1 Automation system, e.g. Simatic S7 (Siemens)
- 2 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or computer with operating tool (e.g. FieldCare, DeviceCare, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 3 Switch, e.g. Scalance X204 (Siemens)

4 Measuring device

Ring topology

This communication interface is available in device versions with PROFINET.



■ 57 Options for remote operation via PROFINET network: ring topology

1 Automation system, e.g. Simatic S7 (Siemens)

- 2 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or computer with operating tool (e.g. FieldCare, DeviceCare, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 3 Switch, e.g. Scalance X204 (Siemens)
- 4 Measuring device


Service interface

Via service interface (CDI-RJ45)

A point-to-point connection can be established to configure the device onsite. With the housing open, the connection is established directly via the service interface (CDI-RJ45) of the device.

- An adapter for RJ45 and the M12 connector is optionally available:
 - Order code for "Accessories", option NB: "Adapter RJ45 M12 (service interface)"

The adapter connects the service interface (CDI-RJ45) to an M12 connector mounted in the cable entry. Therefore the connection to the service interface can be established via an M12 connector without opening the device.




☑ 58 Connection via service interface (CDI-RJ45)

- 1 Computer with Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with "FieldCare", "DeviceCare" operating tool with COM DTM "CDI Communication TCP/IP" or Modbus DTM
- 2 Standard Ethernet connecting cable with RJ45 connector
- 3 Service interface (CDI-RJ45) of the measuring device with access to the integrated Web server

Via WLAN interface

The optional WLAN interface is available on the following device version:

Order code for "Display; operation", option **G** "4-line, illuminated, graphic display; touch control + WLAN"




- 1 Transmitter with integrated WLAN antenna
- 2 Transmitter with external WLAN antenna
- 3 LED lit constantly: WLAN reception is enabled on measuring device
- 4 LED flashing: WLAN connection established between operating unit and measuring device
- 5 Computer with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with operating tool (e.g. FieldCare, DeviceCare)
- 6 Mobile handheld terminal with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or operating tool (e.g. FieldCare, DeviceCare)
- 7 Smart phone or tablet (e.g. Field Xpert SMT70)

Function	WLAN: IEEE 802.11 b/g (2.4 GHz) • Access point with DHCP server (default setting) • Network	
Encryption	WPA2-PSK AES-128 (in accordance with IEEE 802.11i)	
Configurable WLAN channels	1 to 11	
Degree of protection	IP67	
Available antennas	 Internal antenna External antenna (optional) In the event of poor transmission/reception conditions at the place of installation. Available as an accessory →	
Max. range	50 m (164 ft)	
Materials: External WLAN antenna	 Antenna: ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel- plated brass Adapter: Stainless steel and nickel-plated brass Cable: Polyethylene Connector: Nickel-plated brass Angle bracket: Stainless steel 	

Network integration

With the optional OPC-UA-Server application package, the device can be integrated into an Ethernet network via the service interface (CDI-RJ45 and WLAN) and communicate with OPC-UA clients. If the device is used in this way, IT security must be considered.

For permanent access to device data and for device configuration via the Web server, the device is incorporated directly in a network via the service interface (CDI-RJ45). In this way, the device can be accessed any time from the control station. The measured values are processed separately via the inputs and outputs through the automation system.



Supported operating tools	Operating unit	Interface	Additional information
FieldCare SFE500	Notebook, PC or tablet with Microsoft Windows system	CDI-RJ45 service interfaceWLAN interfaceFieldbus protocol	→ 🗎 119
Device Xpert	Field Xpert SFX 100/350/370	HART and FOUNDATION Fieldbus fieldbus protocol	Operating Instructions BA01202S Device description files: Use update function of handheld terminal

Other operating tools based on FDT technology with a device driver such as DTM/iDTM or DD/EDD can be used for device operation. These operating tools are available from the individual manufacturers. Integration into the following operating tools, among others, is supported:

- FactoryTalk AssetCentre (FTAC) by Rockwell Automation → www.rockwellautomation.com
- Process Device Manager (PDM) by Siemens \rightarrow www.siemens.com
- Asset Management Solutions (AMS) by Emerson → www.emersonprocess.com
- FieldCommunicator 375/475 by Emerson → www.emersonprocess.com
- Field Device Manager (FDM) by Honeywell → www.honeywellprocess.com
- FieldMate by Yokogawa → www.yokogawa.com
- PACTWare → www.pactware.com

The associated device description files are available at: www.endress.com \rightarrow Downloads

Web server

Thanks to the integrated Web server, the device can be operated and configured via a Web browser and via a service interface (CDI-RJ45) or via a WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, status information on the device is also displayed and allows the user to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option **G** "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

Supported functions

Data exchange between the operating unit (such as a notebook for example) and the measuring device:

- Upload the configuration from the measuring device (XML format, configuration backup)
- Save the configuration to the measuring device (XML format, restore configuration)
- Export event list (.csv file)
- Export parameter settings (.csv file or PDF file, document the measuring point configuration)
- Export the Heartbeat verification log (PDF file, only available with the "Heartbeat Verification" application package)
- Flash firmware version for device firmware upgrade, for instance
- Download driver for system integration
- − Visualize up to 1000 saved measured values (only available with the **Extended HistoROM** application package $\rightarrow \triangleq 115$)

Web server special documentation \rightarrow 121

HistoROM data management The measuring device features HistoROM data management. HistoROM data management comprises both the storage and import/export of key device and process data, making operation and servicing far more reliable, secure and efficient.



When the device is delivered, the factory settings of the configuration data are stored as a backup in the device memory. This memory can be overwritten with an updated data record, for example after commissioning.

Additional information on the data storage concept

There are different types of data storage units in which device data are stored and used by the device:

	Device memory	T-DAT	S-DAT
Available data	 Event logbook such as diagnostic events for example Parameter data record backup Device firmware package Driver for system integration for exporting via Web server, e.g: GSD for PROFIBUS DP GSD for PROFIBUS PA GSDML for PROFINET EDS for EtherNet/IP DD for FOUNDATION Fieldbus 	 Measured value logging ("Extended HistoROM" order option) Current parameter data record (used by firmware at run time) Peakhold indicator (min/max values) Totalizer values 	 Sensor data: nominal diameter etc. Serial number Calibration data Device configuration (e.g. SW options, fixed I/O or multi I/O)
Storage location	Fixed on the user interface board in the connection compartment	Attachable to the user interface board in the connection compartment	In the sensor plug in the transmitter neck part

Data backup

Automatic

- The most important device data (sensor and transmitter) are automatically saved in the DAT modules
- If the transmitter or measuring device is replaced: once the T-DAT containing the previous device data has been exchanged, the new measuring device is ready for operation again immediately without any errors
- If the sensor is replaced: once the sensor has been replaced, new sensor data are transferred from the S-DAT in the measuring device and the measuring device is ready for operation again immediately without any errors
- If exchanging the electronics module (e.g. I/O electronics module): Once the electronics module has been replaced, the software of the module is compared against the current device firmware. The module software is upgraded or downgraded where necessary. The electronics module is available for use immediately afterwards and no compatibility problems occur.

Manual

Additional parameter data record (complete parameter settings) in the integrated device memory HistoROM backup for:

- Data backup function
 - Backup and subsequent restoration of a device configuration in the device memory HistoROM backup
- Data comparison function Comparison of the current device configuration with the device configuration saved in the device memory HistoROM backup

Data transfer

Manual

- Transfer of a device configuration to another device using the export function of the specific operating tool, e.g. with FieldCare, DeviceCare or Web server: to duplicate the configuration or to store in an archive (e.g. for backup purposes)
- Transmission of the drivers for system integration via Web server, e.g.:
 - GSD for PROFIBUS DP
 - GSD for PROFIBUS PA
 - GSDML for PROFINET
 - EDS for EtherNet/IP
 - DD for FOUNDATION Fieldbus

Event list

Automatic

- Chronological display of up to 20 event messages in the events list
- If the **Extended HistoROM** application package (order option) is enabled: up to 100 event messages are displayed in the events list along with a time stamp, plain text description and remedial measures
- The events list can be exported and displayed via a variety of interfaces and operating tools e.g. DeviceCare, FieldCare or Web server

Data logging

Manual

If the **Extended HistoROM** application package (order option) is enabled:

- Record up to 1000 measured values via 1 to 4 channels
- User configurable recording interval
- Record up to 250 measured values via each of the 4 memory channels
- Export the measured value log via a variety of interfaces and operating tools e.g. FieldCare, DeviceCare or web server

Certificates and approvals

Currently available certificates and approvals can be called up via the product configurator.

CE mark	The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.
	Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.
C-Tick symbol	The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".
Ex approval	The measuring device is certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.
	Devices with the order code for "Approval; transmitter + sensor", option BA, BB, BC or BD have equipment protection level (EPL) Ga/Gb (Zone 0 in the measuring tube).
	The separate Ex documentation (XA) containing all the relevant explosion protection data is available from your Endress+Hauser sales center.

ATEX/IECEx

Currently, the following versions for use in hazardous areas are available:

Ex db eb

Category	Type of protection
II1/2G	Ex db eb ia IIC T6T1 Ga/Gb Ex db eb ia IIB T6T1 Ga/Gb
II2G	Ex db eb ia IIC T6T1 Gb Ex db eb ia IIB T6T1 Gb

Ex db

Category	Type of protection
II1/2G	Ex db ia IIC T6T1 Ga/Gb Ex db ia IIB T6T1 Ga/Gb
II2G	Ex db ia IIC T6T1 Gb Ex db ia IIB T6T1 Gb

Ex ec

Category	Type of protection
II3G	Ex ec IIC T5T1 Gc

Ex tb

Category	Type of protection
II2D	Ex tb IIIC T** °C Db

$_{\rm C}{\rm CSA}_{\rm US}$

Currently, the following versions for use in hazardous areas are available:

IS (Ex i) and XP (Ex d)

- Class I, III, III Division 1 Groups A-G
- Class I, III, III Division 1 Groups C-G

NI (Ex nA)

Class I Division 2 Groups A - D

Ex de

- Class I, Zone 1 AEx/ Ex de ia IIC T6...T1 Ga/Gb Class I, Zone 1 AEx/ Ex de ia IIB T6...T1 Ga/Gb
 Class I, Zone 1 AEx/ Ex de ia IIC T6...T1 Gb Class I, Zone 1 AEx/ Ex de ia IIB T6...T1 Gb
 Ex d
- Class I, Zone 1 AEx/ Ex d ia IIC T6...T1 Ga/Gb Class I, Zone 1 AEx/ Ex d ia IIB T6...T1 Ga/Gb
 Class I, Zone 1 AEx/ Ex d ia IIC T6...T1 Gb
- Class I, Zone 1 AEx/ Ex d ia IIB T6...T1 Gb

Ex nA

Class I, Zone 2 AEx/ Ex nA IIC T5...T1 Gc

Ex tb

Zone 21 AEx/ Ex tb IIIC T** °C Db

Sanitary compatibility	 3-A approval Only devices with the order code for "Additional approval", option LP "3A" have 3-A approval. EHEDG-tested Only devices with the order code for "Additional approval", option LT "EHEDG" have been tested and meet the requirements of the EHEDG. To meet the requirements for EHEDG certification, the device must be used with process connections in accordance with the EHEDG position paper entitled "Easy Cleanable Pipe Couplings and Process Connections" (www.ehedg.org). FDA Food Contact Materials Regulation (EC) 1935/2004 		
Pharmaceutical compatibility	 FDA USP Class VI TSE/BSE Certificate of Suitability 		
Functional safety	The measuring device can be used for flow monitoring systems (min., max., range) up to SIL 2 (single-channel architecture; order code for "Additional approval", option LA) and SIL 3 (multichannel architecture with homogeneous redundancy) and is independently evaluated and certified by the TÜV in accordance with IEC 61508.		
	 The following types of monitoring in safety equipment are possible: Mass flow Volume flow Density 		
	Functional Safety Manual with information on the SIL device $\rightarrow \cong 120$		
HART certification	HART interface		
	 The measuring device is certified and registered by the FieldComm Group. The measuring system meets all the requirements of the following specifications: Certified according to HART 7 The device can also be operated with certified devices of other manufacturers (interoperability) 		

FOUNDATION Fieldbus	FOUNDATION Fieldbus interface			
certification	The measuring device is certified and registered by the FieldComm Group. The measuring system			
	meets all the requirements of the following specifications:			
	 Certified in accordance with FOUNDATION Fieldbus H1 Interoperability Test Kit (ITK), revision version 6.2.0 (certificate available on request) 			
	 Physical Layer Conformance Test 			
	 The device can also be operated with certified devices of other manufacturers (interoperability) 			
Certification PROFIBUS	PROFIBUS interface			
	The measuring device is certified and registered by the PNO (PROFIBUS User Organization Organization). The measuring system meets all the requirements of the following specifications: • Certified in accordance with PROFIBUS PA Profile 3.02 • The device can also be operated with certified devices of other manufacturers (interoperability)			
EtherNet/IP certification	The measuring device is certified and registered by the ODVA (Open Device Vendor Association). The measuring system meets all the requirements of the following specifications: • Certified in accordance with the ODVA Conformance Test • EtherNet/IP Performance Test • EtherNet/IP PlugFest compliance			
	 The device can also be operated with certified devices of other manufacturers (interoperability) 			
Certification PROFINET	PROFINET interface			
	 The measuring device is certified and registered by the PNO (PROFIBUS User Organization Organization). The measuring system meets all the requirements of the following specifications: Certified according to: Test specification for PROFINET devices PROFINET Security Level 2 – Netload Class The device can also be operated with certified devices of other manufacturers (interoperability) 			
Pressure Equipment Directive	The devices can be ordered with or without a PED approval. If a device with a PED approval is required, this must be explicitly stated in the order. For devices with nominal diameters less than or equal to DN 25 (1"), this is neither possible nor necessary.			
	 With the identification PED/G1/x (x = category) on the sensor nameplate, Endress+Hauser confirms conformity with the "Essential Safety Requirements" specified in Appendix I of the Pressure Equipment Directive 2014/68/EU. Devices bearing this marking (PED) are suitable for the following types of medium: Media in Group 1 and 2 with a vapor pressure greater than, or smaller and equal to0.5 bar (7.3 psi) Unstable gases 			
	 Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Article 4 paragraph 3 of the Pressure Equipment Directive 2014/68/EU. The range of application is indicated in tables 6 to 9 in Annex I of the Pressure Equipment Directive 2014/68/EU. 			
Radio approval	The measuring device has radio approval.			
	\square For detailed information on the radio approval, see the Special Documentation \rightarrow \square 121			
Measuring instrument approval	The measuring device is (optionally) approved as a gas meter (MI-002) or component in measuring systems (MI-005) in service subject to legal metrological control in accordance with the European Measuring Instruments Directive 2004/22/EC (MID).			
	The measuring device is qualified to OIML R117 or OIML R137 OIML R117 and has an OIML Certificate of Conformity (optional).			
Additional certification	Marine approval			
	 Currently valid certificates are available: In the Download Area of the Endress+Hauser Internet site: www.endress.com → Downloads Specify the following details: Search area: Approval & Certificates→ Marine 			

CRN approval

Some device versions have CRN approval. A CRN-approved process connection with a CSA approval must be ordered for a CRN-approved device.

Tests and certificates

- Pressure test, internal procedure, inspection certificate
- EN10204-3.1 material certificate, wetted parts and sensor housing
- PMI test (XRF), internal procedure, wetted parts, test report
- EN10204-2.1 confirmation of compliance with the order and EN10204-2.2 test report

Testing of welded connections

	n Test standard Componer				nonont	
Option					Component	
	ISO 23277 AL2x (PT) ISO 10675-1 AL1 (RT, DR)	ASME B31.3 NFS	ASME VIII Div.1 Appx. 4+8	NORSOK M-601	Measuring tube	Process connection
CF	Х				PT	RT
KK		x			PT	RT
KP			x		PT	RT
KR				x	VT, PT	VT, RT
K1	Х				PT	DR
K2		x			PT	DR
K3			x		PT	DR
K4				x	VT, PT	VT, DR
	PT = penetrant testing, RT = 1		ohic testing, \ options with t		testing, DR = digita	l radiography
 EN 60529 Degrees of protection provided by enclosures (IP code) IEC/EN 60068-2-6 Environmental influences: Test procedure - Test Fc: vibrate (sinusoidal). IEC/EN 60068-2-31 Environmental influences: Test procedure - Test Ec: shocks due to rough handling, primarily for devices. EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements IEC/EN 61326 Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements). NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment NAMUR NE 32 Data retention in the event of a power failure in field and control instruments with microprocessors NAMUR NE 43 Standardization of the signal level for the breakdown information of digital transmitters with analog output signal. NAMUR NE 53 Software of field devices and signal-processing devices with digital electronics NAMUR NE 105 Specifications for integrating fieldbus devices in engineering tools for field devices NAMUR NE 107 Self-monitoring and diagnosis of field devices NAMUR NE 131 Requirements for field devices for standard applications 						

- NACE MR0103
- Materials resistant to sulfide stress cracking in corrosive petroleum refining environments. NACE MR0175/ISO 15156-1
- Materials for use in H2S-containing Environments in Oil and Gas Production.
- ETSI EN 300 328 Guidelines for 2.4 GHz radio components.
- EN 301489
 - Electromagnetic compatibility and radio spectrum matters (ERM).

Ordering information

Detailed ordering information is available from the following sources:

- In the Product Configurator on the Endress+Hauser website: www.endress.com -> Click "Corporate" -> Select your country -> Click "Products" -> Select the product using the filters and search field -> Open product page -> The "Configure" button to the right of the product image opens the Product Configurator.
- From your Endress+Hauser Sales Center: www.addresses.endress.com
- Product Configurator the tool for individual product configuration

Up-to-the-minute configuration data

- Depending on the device: Direct input of measuring point-specific information such as measuring range or operating language
- Automatic verification of exclusion criteria
- Automatic creation of the order code and its breakdown in PDF or Excel output format
- Ability to order directly in the Endress+Hauser Online Shop

Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.



Detailed information on the application packages: Special Documentation for the device $\rightarrow \square 120$

Diagnostics functions	Package	Description
	Extended HistoROM	Comprises extended functions concerning the event log and the activation of the measured value memory.
		Event log: Memory volume is extended from 20 message entries (standard version) to up to 100 entries.
		 Data logging (line recorder): Memory capacity for up to 1000 measured values is activated. 250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user. Measured value logs can be accessed via the local display or operating tool e.g. FieldCare, DeviceCare or Web server.

Heartbeat Technology	Package	Description
	Heartbeat Verification +Monitoring	 Heartbeat Verification Meets the requirement for traceable verification to DIN ISO 9001:2008 Chapter 7.6 a) "Control of monitoring and measuring equipment". Functional testing in the installed state without interrupting the process. Traceable verification results on request, including a report. Simple testing process via local operation or other operating interfaces. Clear measuring point assessment (pass/fail) with high test coverage within the framework of manufacturer specifications. Extension of calibration intervals according to operator's risk assessment.
		 Heartbeat Monitoring Continuously supplies data, which are characteristic of the measuring principle, to an external condition monitoring system for the purpose of preventive maintenance or process analysis. These data enable the operator to: Draw conclusions - using these data and other information - about the impact process influences (such as corrosion, abrasion, buildup etc.) have on the measuring performance over time. Schedule servicing in time. Monitor the process or product quality, e.g. gas pockets.

Concentration	Package	Description
	Concentration	Calculation and outputting of fluid concentrations
		 The measured density is converted to the concentration of a substance of a binary mixture using the "Concentration" application package: Choice of predefined fluids (e.g. various sugar solutions, acids, alkalis, salts, ethanol etc.) Common or user-defined units ("Brix, "Plato, % mass, % volume, mol/l etc.) for standard applications. Concentration calculation from user-defined tables.

Special density	Package	Description
	Special density	Many applications use density as a key measured value for monitoring quality or controlling processes. The device measures the density of the fluid as standard and makes this value available to the control system. The "Special Density" application package offers high-precision density measurement over a wide density and temperature range particularly for applications subject to varying process conditions.

Petroleum	Package	Description
	Petroleum	The most important parameters for the Oil & Gas Industry can be calculated and displayed with this application package.
		 Corrected volume flow and calculated reference density in accordance with the "API Manual of Petroleum Measurement Standards, Chapter 11.1" Water content, based on density measurement Weighted mean of the density and temperature

OPC-UA server	Package	Description	
	OPC-UA-Server	The application package provides the user with an integrated OPC-UA server for comprehensive instrument services for IoT and SCADA applications.	
		Special Documentation for the "OPC-UA-Server" application package $\rightarrow \cong 121$.	

Accessories

Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

Device-specific accessories

For the transmitter

Accessories	Description					
Proline 300 transmitter	Transmitter for replacement or storage. Use the order code to define the following specifications: • Approvals • Output • Input • Display/operation • Housing • Software • Order code: 8X3BXX • Installation Instructions EA01150					
Remote display and operating module DKX001	 If ordered directly with the measuring device: Order code for "Display; operation", option O "Separate 4-line display, illum.; 10 m (30 ft)Cable; touch control". If ordered separately: Measuring device: order code for "Display; operation", option M "None, prepared for separate display". DKX001: Via the separate product structure DKX001. If ordered subsequently: DKX001: Via the separate product structure DKX001. Mounting bracket for DKX001 					
	 Ordered directly with the DKX001: Order code for "Enclosed accessories", option RA "Mounting bracket, 1"/2" pipe". If ordered subsequently: order number: 71340960 Connecting cable (replacement cable) 					
	Via the separate product structure: DKX002					
	Further information on display and operating module DKX001 $\rightarrow \triangleq 10$					
	Special Documentation SD01763D					
External WLAN antenna	External WLAN antenna with 1.5 m (59.1 in) connecting cable and two angle brackets. Order code for "Enclosed accessories", option P8 "Wireless antenna wide area".					
	 The external WLAN antenna is not suitable for use in hygienic applications. Further information on the WLAN interface → 106. 					
	Order number: 71351317					
	Installation Instructions EA01238D					
Protective cover	Is used to protect the measuring device from the effects of the weather: e.g. rainwater, excess heating from direct sunlight.					
	Order number: 71343505					
	Installation Instructions EA01160					

For the sensor

Accessories	Description
Heating jacket	Is used to stabilize the temperature of the fluids in the sensor. Water, water vapor and other non-corrosive liquids are permitted for use as fluids.
	If using oil as a heating medium, please consult with Endress+Hauser.
	Heating jackets cannot be used with sensors fitted with a rupture disk.
	 If ordered together with the measuring device: order code for "Enclosed accessories" Option RB "heating jacket, G 1/2" internal thread" Option RC "heating jacket, G 3/4" internal thread" Option RD "Heating jacket, NPT 1/2" internal thread" Option RE "Heating jacket, NPT 3/4" internal thread" If ordered subsequently: Use the order code with the product root DK8003.

Communication-specific	Accessories	Description
accessories	Commubox FXA195	For intrinsically safe HART communication with FieldCare via the USB interface.
	HART	Technical Information TI00404F
	HART Loop Converter HMX50	Is used to evaluate and convert dynamic HART process variables to analog current signals or limit values.
		 Technical Information TI00429F Operating Instructions BA00371F
	Fieldgate FXA320	Gateway for the remote monitoring of connected 4-20 mA measuring devices via a Web browser.
		Technical Information TI00025S Operating Instructions BA00053S
	Fieldgate FXA520	Gateway for the remote diagnostics and remote configuration of connected HART measuring devices via a Web browser.
		Technical Information TI00025S Operating Instructions BA00051S
	Field Xpert SFX350	Field Xpert SFX350 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices and can be used in non-hazardous areas.
		Operating Instructions BA01202S
	Field Xpert SFX370	Field Xpert SFX370 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices and can be used in the non-hazardous area and in the hazardous area.
		Operating Instructions BA01202S
	Field Xpert SMT70	The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress. This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.
		 Technical Information TI01342S Operating Instructions BA01709S Product page: www.endress.com/smt70

Service-specific accessories	Accessories	Description
	Applicator	 Software for selecting and sizing Endress+Hauser measuring devices: Choice of measuring devices for industrial requirements Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, flow velocity and accuracy. Graphic illustration of the calculation results Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project. Applicator is available:
		 Via the Internet: https://portal.endress.com/webapp/applicator As a downloadable DVD for local PC installation.
	W@M	W@M Life Cycle ManagementImproved productivity with information at your fingertips. Data relevant to a plantand its components is generated from the first stages of planning and during theasset's complete life cycle.W@M Life Cycle Management is an open and flexible information platform withonline and on-site tools. Instant access for your staff to current, in-depth datashortens your plant's engineering time, speeds up procurement processes andincreases plant uptime.Combined with the right services, W@M Life Cycle Management boostsproductivity in every phase. For more information, visitwww.endress.com/lifecyclemanagement
	FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition. Operating Instructions BA00027S and BA00059S
	DeviceCare	Tool to connect and configure Endress+Hauser field devices.

System components	Accessories	Description
	Memograph M graphic data manager	The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.
		 Technical Information TI00133R Operating Instructions BA00247R
	Cerabar M	The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.
		 Technical Information TI00426P and TI00436P Operating Instructions BA00200P and BA00382P
	Cerabar S	The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.
		 Technical Information TI00383P Operating Instructions BA00271P
	iTEMP	The temperature transmitters can be used in all applications and are suitable for the measurement of gases, steam and liquids. They can be used to read in the medium temperature.
		Fields of Activity" document FA00006T

Supplementary documentation

- For an overview of the scope of the associated Technical Documentation, refer to the following: • W@M Device Viewer (www.endress.com/deviceviewer): Enter the serial number from
 - nameplate *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2D matrix code (QR code) on the nameplate

Standard documentation Brief Operating Instructions

Brief Operating Instructions for the sensor

Measuring device	Documentation code
Proline Promass F	KA01261D

Brief Operating Instructions for transmitter

	Documentation code						
Measuring device	HART	FOUNDATION Fieldbus	PROFIBUS PA	PROFIBUS DP	Modbus RS485	EtherNet/IP	PROFINET
Proline 300	KA01309D	KA01229D	KA01227D	KA01386D	KA01311D	KA01339D	KA01341D

Operating Instructions

Measuring device	Documentation code						
	HART	HARTFOUNDATION FieldbusPROFIBUS PAPROFIBUS DPModbus RS485EtherNet/IPPROFINET					PROFINET
Promass F 300	BA01485D	BA01518D	BA01507D	BA01850D	BA01496D	BA01728D	BA01739D

Description of Device Parameters

	Documentation code						
Measuring device	HART	FOUNDATION Fieldbus	PROFIBUS PA	PROFIBUS DP	Modbus RS485	EtherNet/IP	PROFINET
Promass 300	GP01057D	GP01094D	GP01058D	GP01134D	GP01059D	GP01114D	GP01115D

Device-dependent

Safety instructions

additional documentation Safety instruct

Safety instructions for electrical equipment for hazardous areas.

Contents	Documentation code
ATEX/IECEx Ex d/Ex de	XA01405D
ATEX/IECEx Ex ec	XA01439D
cCSAus XP	XA01373D
cCSAus Ex d/ Ex de	XA01372D
cCSAus Ex nA	XA01507D
INMETRO Ex d/Ex de	XA01468D
INMETRO Ex ec	XA01470D
NEPSI Ex d/Ex de	XA01469D
NEPSI Ex nA	XA01471D

Remote display and operating module DKX001

Contents	Documentation code
ATEX/IECEx Ex i	XA01494D
ATEX/IECEx Ex ec	XA01498D
cCSAus IS	XA01499D
cCSAus Ex nA	XA01513D
INMETRO Ex i	XA01500D
INMETRO Ex ec	XA01501D
NEPSI Ex i	XA01502D
NEPSI Ex nA	XA01503D

Special Documentation

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01614D
Functional Safety Manual	SD01727D
Remote display and operating module DKX001	SD01763D
Radio approvals for WLAN interface for A309/A310 display module	SD01793D
OPC-UA Server 1)	SD02039D

1) This Special Documentation is only available for device versions with a HART output.

Contents	Documentation code						
	HART	FOUNDATION Fieldbus	PROFIBUS PA	PROFIBUS DP	Modbus RS485	PROFINET	EtherNet/IP
Web server	SD01662D	SD01665D	SD01664D	SD02226D	SD01663D	SD01969D	SD01968D
Heartbeat Technology	SD01642D	SD01696D	SD01698D	SD02202D	SD01697D	SD01988D	SD01982
Concentration measurement	SD01644D	SD01706D	SD01708D	SD02212D	SD01707D	SD02005D	SD02004D
Petroleum	SD02097D	-	SD02291D	SD02216D	SD02098D	SD02099D	SD02096D
Custody transfer	SD01688D	-	-	-	SD01689D	-	-

Installation Instructions

Contents	Comment		
Installation instructions for spare part sets and accessories	Documentation code: specified for each individual accessory .		

Registered trademarks

HART®

Registered trademark of the FieldComm Group, Austin, Texas, USA **PROFIBUS®** Registered trademark of the PROFIBUS User Organization, Karlsruhe, Germany **FOUNDATION™ Fieldbus** Registration-pending trademark of the FieldComm Group, Austin, Texas, USA **Modbus®** Registered trademark of SCHNEIDER AUTOMATION, INC.

EtherNet/IP™ Trademark of ODVA, Inc.

PROFINET®

Registered trademark of the PROFIBUS User Organization, Karlsruhe, Germany

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

www.addresses.endress.com

